

iPECS

WIT-400HE

User Guide

Please read this User Guide carefully before operating your set. Retain it for future reference.

iPECS is an Ericsson-LG Brand



Regulatory Notes and Statements

Wireless LAN, Health and Authorization for use

Radio frequency electromagnetic energy is emitted from Wireless LAN devices. This energy levels of these emissions, however, are far much less than the electromagnetic energy emissions from wireless devices such as mobile phones. Wireless LAN devices are safe for use by consumers because they operate within the guidelines found in radio frequency safety standards and recommendations. The use of Wireless LAN devices may be restricted in some situations or environments, such as :

- On board an airplane, or
- In an explosive environment, or
- In situations where the interference risk to other devices or services is perceived or identified as harmful.

In cases in which the policy regarding use of Wireless LAN devices in specific environments is not clear (e.g., airports, hospitals, chemical/oil/gas industrial plants, private buildings), obtain authorization to use these devices prior to operation the equipment.

Regulatory Information / Disclaimers

"Privacy of communications may not be ensured when using this telephone". Any changes or modifications made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment. The Manufacturer is not responsible for any radio or television interference caused by unauthorized modification of this device, or the substitution or attachment of connecting cables and equipment other than those specified by the manufacturer. It is the responsibility for the user to correct any interference caused by such unauthorized modification, substitution or attachment. The manufacturer and its authorized resellers or distributors will assume no liability for any damage or violation of government regulations arising from failure to comply with these guideline.

USA-FCC (Federal Communications Commission) Statement

This device complies with Part 15 rules. Operation is subject to the following two conditions;

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement (for User manual)

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment. This equipment generates, uses, and radiates radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference. However,

there is no guarantee that interference will not occur. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one of the following measures;

1. Reorient or relocate the receiving antenna.
2. Increase separation between the equipment and receiver.
3. Connect the equipment to an outlet on a circuit different from which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician.

Compliance Statement for Canada

This Class B digital apparatus meets all requirements of the Canadian Interface-Causing Equipment Regulations. "Cet appareil de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada." The device is certified to the requirements of RSS-210 for 2.4GHz spread spectrum devices. The use of this device in a system operating either partially or completely outdoors may require the user to obtain a license for the system according to the Canadian regulations. For further information contact your Local Industry Canada office.

European Union Declarations of Conformity

Ericsson-LG Co., Ltd. declares that the equipment specified in this document bearing the "CE" mark conforms to the European Union Radio and Telecommunications Terminal Equipment Directive (R&TTE 1999/5/EC), including the Electromagnetic Compatibility Directive (2004/108/EC) and Low Voltage Directive (2006/95/EC). Copies of these Declarations of Conformity (DoCs) can be obtained by contacting your local sales representative.

The Product is CE marked.

The product fulfills the essential requirements of the harmonized standards shown above.

Product Safety Instructions

This product complies with and conforms to the following international Product Safety standards as applicable:

Safety of Information Technology Equipment, IEC60950-1, including all relevant national deviations as listed in Compliance with IEC for Electrical Equipment (IECEE)

Safety of Information Technology Equipment, CAN/CSA-C22.2 No. 60950-1/UL 60950-1

Specific absorption rate (SAR), in Compliance with EN50360 + A1, EN622091-1, FCC OET Bulletin 65 Supplement C, IEEE 1528 and ANSI/IEEE C95.1, C95.3

Hearing Aid Comparability and Volume Control, in Compliance with IC CS03 Part V Issue 9

Issue	Release Date	Changes
1.0	Mar 18, 2013	New Product Release

Contents

Before Starting	1
Important Safety Informations	1
Inside the Package	5
Phone Basics	7
Your Phone.....	7
Display Screen	10
Getting Started	13
Battery and Charger	13
Turning Your Phone On and Off.....	16
Navigating Through Menus and Options	17
Entering Text	18
Headset with Mic	21
Phone Carrying	22
Access Point.....	23
Registration	25
Range.....	26
Signal Strength.....	27
Access Point Probing.....	27
Caller ID	27
Cleaning Phone.....	27
Phone's Menu	28

Phone Calls	31
Making Calls	31
Answering Calls.....	34
In Call Options	34
Using Quickly Change Mode	35
Using Keypad Lock (Keyguard)	36
Phone Book	37
About Phone Book (Contacts).....	37
Add New	38
Search Phonebook.....	40
Caller Groups.....	41
Speed Dials	44
Delete All	46
Sound	47
Alert By	47
Ring Tone	47
Ring Tone Volume	48
Power-On Tone.....	48
Power-Off Tone.....	48
Key Tone.....	49
Key Tone Volume	49
Effect Sound	49
Display	51
Screen Theme	51
Greeting Note	52
Idle Clock	52
Dialing Font	52
Menu Style	53
Backlight.....	53

Font Type	53
Language.....	54
Call History	55
Call History	55
Call Duration	57
Messages.....	59
Viewing Message.....	59
Writing Text Message.....	60
Inbox	61
Outbox.....	62
Draft.....	62
Templates	63
Tools.....	65
Schedule	65
Memo.....	70
Alarm Clock.....	71
Calculator	73
World Time.....	73
Timer	74
System.....	77
Call Forward.....	77
3-Party Conference	79
DND (Do Not Disturb).....	80
Message Waiting/Call Back.....	80
Flash.....	82
System Speed	82
System Redial.....	86
ICM (Intercom).....	86
Mute	87

Call Transfer.....	87
Hold/Save	88
Program.....	88
Settings.....	89
Profile Settings	89
System Setting.....	95
Codec Preference	96
Wireless LAN Setting.....	97
Security.....	97
Wireless LAN Status	97
Network Information	98
Phone Version.....	98
Reset Settings	98
Useful Information	99
Before Service Inquiry.....	99
Troubleshooting	102
Specification.....	103
Caring for the Battery	105
Open Source Software Notice.....	106
Caring for the Environment by Recycling.....	107
Index	109

Before Starting

Important Safety Informations

Important safety informations that will help you safely use your phone. Failure to read and follow the important safety information in this phone user guide may result in serious bodily injury, death, or property damage.



WARNING: Violation of the instructions may cause serious injury or death.



CAUTION: Violation of the instructions may cause minor or serious damage to the product.

CAUTION: Location and Environment for the Installation

- Install the product strictly following the user guide included in the product. If not, the product would not function or its lifetime could be shortened.
- Avoid installing the product towards the direct ray of the sun or in locations exposed to direct sunlight, on carpets or cushions. If not, the phone could be damaged, or fire or electric shock could be caused.
- Avoid installing the product in dusty locations. If not, sand could be intruded into the phone, and fire, electric shock or other product defects can occur.
- Avoid installing the product in the locations where a strong vibration exists. If not, the product performance could decline or its lifetime could be shortened.
- Do not place vase, cosmetics or containers filled with water, milk or beverage in proximity to the product. The liquid spilt out could cause fire, electric shock, malfunction, etc.

- Avoid installing the product near fire or in a small space with poor-ventilation. If not, fire or product defects could be caused.
- Do not put the phone inside a washing machine or a microwave. It could cause explosion, problems, deformation or defects.
- Avoid installing the product on a shelf or a slanted surface. If not, the product could fall, causing personal injuries or defects on the phone.
- Avoid installing the product close to other electronic products such as TV, audio instruments, etc. It may cause some noises due to electromagnetic interference. Properly install the base away from such products.
- Avoid installing or using the product near kitchen utensils such as cooking table, humidifier, rice-cooker, etc., or in locations exposed to rain and wind or such places as bathroom where water might be splashed. Electric shock, fire, deformation or product defects could be caused.

WARNING: Power Supply

- Remove dust from the power plug pin and insert the power plug tightly into power receptacle. If not, fire or electric shock could be caused.
- Do not use a damaged or loosened plug, and do not modify or damage the power cord. Fire or electric shock could be caused.
- Do not connect a multiple number of cords into a single power connector. Fire or electric shock could be caused.
- Do not touch the power plug with wet hands and grasp the power supply plug when unplugging the power cord. Fire or electric shock could be caused.
- Do not cover the power cord and the adaptor with a pad, and do not place them near heating instruments. Do not let children or pets bite the phone or the power cable. Fire or electric shock could be caused.
- Use the adaptor that was included in the product package (See the product specification). Check the rated voltage at home. Using other voltages may cause a fire.
- Ensure that the external cords of the phone are disconnected before it is moved from the installation site. If not, fire or electric shock could be caused.
- Do not bend the power cord reluctantly, and do not place a heavy instrument on the power cord. Fire or electric shock could be caused.

WARNING: Battery Handling

- Do not disassemble or revise the battery and do not use it for other purposes. Use the specified battery and adaptor only. Fire or personal injury may be caused by heat or rupture.
- If the battery is damaged, the battery liquid may leak out. Take care not to contact the battery leakage. Keep it away from your eyes, skin or cloths. If there is any contact, immediately clean it with water and take medical care as soon as possible.
- Dispose the used battery in a specified place. Improper treatment may cause an unexpected accident.
- Do not apply impact on the battery by throwing it, and do not place it close to heating instruments (microwave, heater). The battery liquid may leak out, or fire or explosion may be caused.
- Never damage the shield tube nor contact the \oplus and \ominus pins of the battery with a metal. Fire or physical injury may be caused by heat or rupture.
- Do not store the battery in locations exposed to direct sunlight or with high temperature and humidity (store it in a room at $0^{\circ}\sim +40^{\circ}$). Deformation or explosion could be caused.
- Do not let children or pets suck or bite the battery. Putting the battery into mouth is harmful for human body. Should a child swallow the battery, consult a physician as soon as possible.
- If you detect smokes or a strange smell while using the phone or charging the battery, unplug the power cord and contact the service center. Using it in such condition may cause fire or an electric shock.

CAUTION: Operation

- Do not let anybody disassemble or alter the device other than qualified service personnel. Contact the distributor and the customer service center for the inspection and repair. Fire, an electric shock or problems could be caused.
- Do not touch the power plug during lightning storms. It can cause an electric shock or death.
- Be careful not to let any foreign materials get into the product. In particular, if a staple and pins are magnetized on the receiver, make sure to eliminate it before use. Using it in such condition may cause fire, electric shock, or injury especially on the face.
- Do not drop objects or apply impact on the phone. The phone could be damaged, or personal injury or product defects could be caused.

- If you detect a burning smell or smoke, immediately stop using the product, disconnect the power supply plug and the phone cable and contact the service center. Using it in such condition may cause fire or electric shock.
- Pay attention not to let the phone contact with volatile substances (benzene, thinner, alcohol, acetone, etc.) If not, fire, deformation or decolorization could be caused.
- Pay attention not to be stumbled over the phone cable or power cord. Accident, injury or product defects could be caused.
- Do not let water penetrate into the product. Should water penetrate into the product, disconnect the power supply plug and the phone cable and contact the distributor or the service center. Using it in such condition may cause electric shock.
- Do not drop the phone during operation and do not throw it toward a person. If the product is dropped and damaged, disconnect the power supply plug and contact the distributor or the service center. The phone could be damaged, or accident, personal injury or product defects could be caused.
- Avoid using the phone where there is a gas leakage. If there is a gas leakage, do not touch the phone, phone cord and receptacle with hands and open the window for ventilation. Flames may cause explosion, resulting in fire or burn injury.
- When the charging contacts are wet with water or stained with foreign materials, use the product after wiping them with dry towel. Using it in such condition may cause accident, injury or product problems.
- Do not cover the phone with wrap or vinyl for packing. The coating may peel away.
- Pay attention not to hurt with the edges or angles of the product, and be careful not to let a child put the mic or power cord into the mouth. If not, it can cause an accident, injury or product defects.
- Never place your ears in proximity to the speaker hole, nor insert a driver or tweezers into the hole of product. This may result in accident, injury or defects of the product.
- Separately record and keep the data of the phone. Since important data stored in the memory could be lost by user's carelessness or during repair or upgrade of the product, keep important numbers and texts in a separate record. Note that the manufacturer is not liable to any damage resulting from data loss.

Inside the Package

The following items are included in your phone package. Before using the phone, ensure that you have the following package contents. If something is missing or not functioning, contact your local distributor.



WIT-400HE



Charger

Connect the Travel Adapter to Charger, then plug it into the electrical outlet to charge the battery.



Travel Adapter

Use to charge the battery without Charger.



Headset

Use the built-in microphone to talk.



Lithium Ion (Li-Ion) Battery
(3.7V, 1150mAh)



Wrist Strap

Attaches to carry your phone.



Quick Start Guide

All you need to know to get going.



Optional Belt Clip
(Not included)


CAUTION: Use only Ericsson-LG approved items with your phone. Failure to do this may damage the phone and invalidate your warranty.

Note: The illustrations are used for explanation purposes, some of it may differ slightly from what shown.

Your Phone

The following illustration will help you become familiar with your new Wireless IP Phone.

Phone Layout



* This phone has an internal antenna. Avoid touching the antenna area unnecessarily while the antenna is transmitting or receiving. Contact with the antenna affects communication quality.

Key Functions

The following list gives a brief description of all available key functions of your phone.


1. **Earpiece** lets you hear the caller.
2. **Display Screen** displays all the information needed to operate your phone, such as the call status, the date and time, and the signal and battery strength.
3. **Navigation/OK (⊙) Key** scrolls through the phone's menu options and acts as a shortcut key from standby mode^{*1} and selects the highlighted choice when navigating through a menu.
 - Press **Up** (⬆) to access **Searching SSID**.
 - Press **Down** (⬇) to access **Schedule**.
 - Press **Left** (⬅) to access **System**.
 - Press **Right** (➡) to access **Messages**.
4. **Left Softkey**^{*2} lets you access menu items or select softkey actions corresponding to the bottom left line on the display screen.
5. **Hold/Save Key** allows you to place a call on hold. Use to save your changes while in the programming mode.
6. **Send key** allows you to place or receive calls, or use call history.
7. **Alphanumeric Keypad** lets you enter numbers, characters, and navigate within menus. Press and hold keys from 1 to 9 for speed dialing.
8. **Manner Mode** allows you to activate the vibration mode from standby mode.
9. **Mic** lets you transmit your voice.
10. **Right Softkey** lets you access the contact list or select softkey actions corresponding to the bottom right line on the display screen.
11. **Trans/PGM Key** allows you to transfer an active call. Pressing this key accesses the menu for making changes to the IP phone configuration in standby mode.
12. **End/Power Key** lets you turn the phone on or off, end a call, or return to standby mode. While in the main menu, it returns the phone to standby mode and cancels your input.

13. **Clear Key** deletes single spaces or characters with a quick tuch, but press and hold to delete entire words from the display in text entry mode. When in a menu, press this key to return to the previous menu.
Keypad Lock allows you to lock the phone's keypad immediately in standby mode by pressing and holding it about two seconds.
 14. **Lock Mode** allows you to lock the phone from standby mode.
 15. **Strap Eyelet** allows you to connect the wrist strap.
 16. **Push-to-Talk(PTT)** allows you to invoke announcements to other numbers of the PTT group in standby mode.
 17. **Speaker** lets you hear the different ringtones and sounds.
 18. **Side Volume Key** allows you to adjust the key tone volume in standby mode or adjust the earpiece volume during a call.The side volume key can also be used to scroll up or down to navigate through the different menu options.
 19. **Headset Jack** allows you to plug in a mono headset for convenient, hands-free conversations.
 20. **Battery Cover** push the back cover downward to remove it.
 21. **Charger Jack** allows you to plug in your travel adapter to your phone, first open the external charger jack cover.
- *1 A standby mode is when the phone is ready for use. No menu is displayed and the phone is not performing any action. It is starting point for all of the instruction steps, the phone is in the standby mode.
- *2 The roles of these soft keys vary according to the applications, each menu and option lets you view and alter the settings of a specific function use the left and right soft keys.

Display Screen









The display screen provides information about your phone's status and/or action of the functions shown after successful registration.

Display Informations




Status Icons

The following list gives a brief description of all showing status icons of your phone. You will see this kind of icon at the top of the screen.


-  shows your current signal RSSI level.^{*1} The more lines you have, the stronger your signal.
 -  means your phone is not registered within the required AP^{*2} or when your phone is out of range.
 -  indicates your phone is trying to find the AP.
-  tells you a call is in progress or call is connected.
 -  means your phone cannot find a system signal or cannot make a call.
-  indicates phone lock is activated or keypad lock.
-  indicates ringtone Vibration or Vibration Once.
 -  indicates ringtone Ring after Vibration or Ring & Vibration.


 indicates ringtone off or Mute is set.

 indicates manner mode is activated. Quickly set to vibration mode, phone always vibrates instead of making a sound.

5.  indicates you have new text messages.

6.  indicates you have Message Waiting/Call Back.

7.  indicates alarm is activated.

8.  represents the amount of remaining battery charge currently available in your phone.

 indicates low battery.

 indicates almost running out battery.

 indicates starting low battery.

 indicates full battery.

 indicates charging low battery.

¹ A RSSI (Received Signal Strength Indication) is a value representing the received radio signal strength of the access point. You can see RSSI level icon while the phone is operating.

² An AP (access point) is device that allow wireless communication devices to connect to the network. They are usually connected to the wired network and allow communication between the wired and wireless devices.

Main Menu


When the phone is switched on and standby mode press left softkey to access the main menu.

• Standby Mode



Press  [Menu] and select "Sound" menu.









• Menu Mode



Highlighted icon indicates that Sound menu is selected.

Main Menu Icons


These icons are used to access the following your phone's main menu options as described in table.

Icon	Description
	This icon refers to the menus related to Phone Book.
	This icon refers to the menus related to Sound for user's customization.
	This icon refers to the menus related to Display for user's customization.
	This icon refers to the menus related to Call History.
	This icon refers to the menus related to Messages.
	This icon refers to the menus related to Tools for user's convenience.
	This icon refers to the menus related to Systems that provides a user with variety of keyphone features.
	This icon refers to the menus related to Settings of your phone.


State Displays

The phone will show both items on the display screen, if the caller's name and number are stored in your Phone Book. If not, phone will only display the phone number. The following examples show the call state displays.

• Incoming Call



• Outgoing Call



Battery and Charger

Your phone is equipped with a Lithium Ion (Li-Ion) battery. It allows you to recharge your battery before it is fully drained.

WARNING: Use only Ericsson-LG approved battery, charger, and Power Adapter with your phone. The failure to use a Ericsson-LG approved battery, charger, and Power Adapter may increase the risk that your phone will overheat, catch fire, or explode, resulting in serious bodily injury, death, or property damage.


When the battery reaches 10% of its capacity, your phone makes a sound and displays a message. When there are approximately four minutes of talk time left, the phone sounds an audible alert and then turns off.

Installing and Removing the Battery


Always turn off your phone before installing or replacing the battery.

To install the battery:


1. With your thumb, press down on the battery cover on the back of your phone (1) and slide it downward to release it (2).



2. Remove the battery cover from the back of the phone.
3. Insert the battery into the opening, making sure the connectors align (1). Gently press down to secure the battery (2). **Note:** Do not force the battery.



4. Replace the battery cover (1) and press up until you hear a click to lock the cover into place (2).



To remove the battery:


1. Make sure the power is off so that you do not lose any stored numbers or messages.
2. Use your thumb press down battery release hook on the back of your phone and remove the battery from the phone.

WARNING: Do not handle a damaged or leaking Li-Ion battery as you can be burned.

Note: The battery has limited lifespans and the battery is warranted for a period of 6 months from the purchasing date.

Charging the Battery


When you use phone for the first time, the battery is not fully charged. Fully charge your battery as soon as possible so you can begin using the phone.



An icon located in the upper right corner of the display screen shows battery charging status. If the battery charge is getting too low, the battery icon  blinks and the phone sounds a warning tone.

Always use an Ericsson-LG approved charger or power adapter to charge your battery.

To install the charger:

1. Plug the flat end of the travel adapter into the charger's charging jack (1) and the other end into an electrical outlet (2). **CAUTION:** Using incompatible accessory may damage the phone.



2. Charge the battery by placing the phone on the charger. With the approved Li-Ion battery, you can recharge the battery before it becomes completely run down.
 - As the battery is being charged while the power is on, a charging  icon appears on the display screen. After the battery has been fully charged, a full battery  icon appears on the display screen. (Refer to "Status Icons" on page 10.)
 - On the charger color indicator LED means that:
 - A red (●) means the battery is charging or recharging.
 - A green (●) means the battery is at least 99 percent charged.
 - Estimated battery (Li-Ion 3.7V 950mAh) charging time is approximately 5 hours.
 - If the battery cannot be charged correctly, turn off the power once, remove the battery, and then reinstall it to charge the battery again.

To install the travel adapter:

- ▶ Open the external charger jack cover (❶) of the phone. Plug the flat end of the travel charger into the phone's charger jack (❷) and the other end into an electrical outlet (❸).



Replacing the Battery



Rechargeable battery has a limited number of charge cycles and may eventually need to be replaced.



- The charging time may differ depending on the condition of your battery, purchases a new battery when the battery run time gets shortened.
- Use only the Li-Ion battery supplied with your phone. New batteries are available from Ericsson-LG.

Turning Your Phone On and Off

Turning Your Phone On


- ▶ Press and hold  for approximately two seconds.

After the powering on animation, the phone tries to lock the access point. As your phone connects to the access point, you see an Antenna  and RSSI level  icon on the display screen, it means all procedures for initial setup are completed.

Your screen still remains , the phone searches for and sends a registration message to system. If the phone receives Register Response,  icon disappears from the display screen.

Setup and registration is completed, your phone automatically goes to standby mode, you can make or receive any type of call. **If not, see "Registration" on page 25.**

Turning Your Phone Off

- ▶ Press and hold  for three seconds until you see the powering down animation on the display screen.

Navigating Through Menus and Options








Your phone has a simple on screen menu to navigate. Each menu has a list of options. (See "Phone's Menu" on page 28.)

The navigation key on your phone lets you scroll through menus easily. Some of the items you selected has a vertical scroll bar at the right-hand side of the screen keeps track of your position in the menu at all times.

Currently your phone's menu view style is "List view", to change your phone's menu view see "Menu Style" on page 53.

Selecting Menu Items




When the phone is switched on and in standby mode:


1. Press  to access the main menu.
2. Use the  to highlight the menu you want and press .
3. When the menu item you want is displayed, press:
 -  to select the highlighted option.
 -  to go to the previous menu.
 -  to scroll through the list of options.
 -  to return to standby mode.

Pressing the Corresponding Number

You can quickly select a desired menu by pressing corresponding number instead of navigating through menus with navigationkey.

When the phone is switched on and in standby mode:

1. Check the desired menu, referring to the "Phone's Menu" on page 28. Phone's Menu table shows the available menu structure and indicates the number assigned to each menu option.
2. Press  to access the main menu.
3. Press the number assigned to menu. For example, if you want to select "Screen Theme" press the corresponding number on the phone's keypad as below ", 





Entering Text

You can enter alphanumeric characters using the keypad of the phone.





Selecting a Text Input Mode




Your phone provides convenient ways to enter letters, punctuations, numbers, and symbols whenever you are prompted to enter text (for example, when adding a Phonebook or when composing text and memo).

1. From a screen where you can enter text, press  to change the text input mode to: abc, ABC, or 123.
 - Shows the text input mode indicator in the bottom right line on the display screen.
2. Select one of the following options:
 - **abc and ABC** to cycle through the alpha characters associated with the letters on the keypad.
 - **abc** to enter lower case letters,
 - **ABC** to enter upper case only.
 - **123** to enter numbers by pressing the numbers on the keypad.
3. When you enter the text, press  and choose one of the following options:
 - **Common Terms** to enter preprogrammed messages (see page 20).
 - **Search Phonebook** to find saved entries (see page 40).
 - **Symbol** to enter symbols (see page 20).
 - **Smiley** to enter "emoticons" (see page 20).
 - **Cancel** to cancel writing.

Using ABC Mode













Using keys 2 through 9, press the key labeled with the desired letter. Once for the first letter, twice for the second letter, and so on.

1. Select the **abc** mode.
2. Press the corresponding keys repeatedly until the desired letter appears. For example, to enter the word "good," press  once,  three times,  three times again, and  once.
 - If the next letter you want is located on the same key as the present one, wait until the cursor appear and enter the letter.

- The most common punctuation marks such as the "Period", "Comma", "Question", and "Exclamation" are available under the .
- If you make a mistake, press  to erase a single character. Press and hold  to erase an entire word.



The following table shows you where each letter can be found on the phone's keypad. After a character is entered, the cursor automatically advances to the next space after two seconds or when you enter a character on a different key.

Characters scroll in the following order:

Key	Sequence in upper case	Sequence in lower case
	@ : /	@ : /
	A B C 2	a b c 2
	D E F 3	d e f 3
	G H I 4	g h i 4
	J K L 5	j k l 5
	M N O 6	m n o 6
	P Q R S 7	p q r s 7
	T U V 8	t u v 8
	W X Y Z 9	w x y z 9
	.,?!	.,?!
	*	*
	#	#

Using 123 Mode


The 123 Mode enables you to enter numbers in a text messages (a telephone number, for example).

1. Select the **123** mode.
2. Press the appropriate keys to the required digits.
 - If you make a mistake, press  to erase a single character. Press and hold  to erase an entire word.

Entering Common Terms, Symbols and Smileys




To enter common terms:

Common terms make composing text messages easier by allowing you to enter quick messages, such as "Please, Call me back!", "I'm late. I'll be there at.", "Where are you now?" or a customized message of your own. (For more information on preset messages, please see "Templates" on page 63.)

1. Select the **Common Terms** mode.
2. Select a preset message and press .


To enter symbols:

Symbols enable you to enter punctuation and other symbols. When you enter the text, insert a space between the text and also force a line break at a specific location in the text message.

1. Select the **Symbols** mode.
2. To insert a space, move the cursor where you want to insert a space and press .
3. To force a line break, move the cursor where you want to break a line and press .
4. To enter a symbol, press the appropriate key indicated on the display and press .

To enter smileys (emoticons):

An emoticon is a symbol used in text messages to show how someone is feeling.

1. Select the **Smiley** mode.
2. To enter an emoticon, press the appropriate key indicated on the display and press .

Headset with Mic

The headset included with phone features a microphone and an integrated button that allows you to answer and end calls easily.


Connecting the Headset

- ▶ Open the headset jack cover and flip it over (❶) and plug the headset into phone's headset jack (❷).

CAUTION: Using incompatible accessory may damage the phone.

WARNING: Do not insert any external substance except headset in the headset jack. Inserting anything except for headset provided by general maker may cause severe damage the phone.

- Plug in the headset to make or answer a phone call. Callers hear you through the headset microphone.
- Even though the headset is plugged, incoming call ring tone is heard through the speaker, not through the headset.



Press the mic button to control answer, hold, switch and end calls.

Standby mode:

Answering an incoming call	Press once.
Go to the Call List	Press once.
Redial call the most recent number in the Call List	Press and hold for about two seconds.

During a call:

End the current call	Press and hold for about two seconds.
----------------------	---------------------------------------


Phone Carrying

Using the Wrist Strap

Carry your phone with the wrist strap that included in your package. This polyester carrying strap attaches easily to your phone.

To connect the wrist strap:

- ▶ Thread the small loop of the wrist strap through the strap hole on the phone (1) and pull the strap through the small loop until the strap is firmly secured (2).



Using the Belt Clip (User Opinions)


The phone belt clip allows you to clip your phone to your belt or pocket when you work around the office.

Note: This belt clip is not included in your package.




To attach the belt clip:

- ▶ To attach the belt clip remove the protective cover from the back of the phone as indicated below (1) then tighten the screw that provided with the belt clip (2). Place the belt clip, align the screw on the back of the phone and push it up hard until the belt clip is firmly secured (3).



To remove the belt clip:

- ▶ To release the belt clip use your thumb push down on the unlock button located on the upper side of the belt clip as shown in the illustration below (1) and extract it from the phone (2).



Access Point

Depending on the internal implementation of IEEE802.11b/g protocol inside of the APs, roaming across two contiguous regions may be affected. Cisco is currently showing the most optimized seamless roaming.

The CISCO APs are strongly recommended to customers.

The following is a list of APs that have been made an imperative experimentation with the WIT-400HE and the result.

AP	Cisco-AP1231G	Cisco-AP1121G
Rank	Best	Good
Max Retry Counter	O	O
Simultaneous Call	12	10
Reject after Full Association	X	X
Roaming	O	O
Multiple SSID	O	O
Power Control	O	O
WPA	O	O

Max retry counter : It's the maximum retry counter of data packet from AP to client. If the retry counter of a packet exceeds the limit, the packet is discarded. If the AP doesn't support max retry counter, it can make network busy by excessive retransmit when a user goes to out-of-range in conversation.

When the receiving packet rate is very low during 10 seconds, WIT-400HE disconnects the call to prevent excessive retransmit of packets.

The simultaneous calls are estimated in idle network configuration, so it can be decreased by the network condition. When the AP is commonly used for data and voice, the bandwidth for voice call will be decreased. If you use overlapping channels, radio frequency interference can occur, which leads to connectivity issues and in poor throughput.

Reject after Full Association: This feature support to restrict the number of association simultaneously for load balancing.

Roaming: It means that the call in conversation is not disconnected when it roams to other AP. To support seamless roaming, the signal range of each AP should be overlapped.

If you need to use roaming feature, we strongly recommend Cisco AP. The other APs above support roaming but they are unstable. We found that sometime the AP doesn't send packets after roaming in our laboratory investigation.

Recommended AP specification for WIT-400HE

To recommend proper Access Point for WIT-400HE, Ericsson-LG specified as the following list.

No	Item	Description
1	802.11 b/g	802.11 b/g should be supported.
2	Simultaneous call	Minimum 4 simultaneous calls should be supported.
3	Reject access when full traffic	It can be adjusted in the admin program.
4	Max retry counter	It can be set in the admin program or should not be transmitted.

5	Continuous call	Long term call(longer 12 hours) should be supported.
6	Roaming within same kind of AP	Seamless handover/roaming should be supported. AP should support IAPP for roaming between APs.
7	Traffic distance	Longer than 200 meters.
8	Antenna diversity	More than 2 antennas.
9	AP manager	AP manager can some configuration like channel, SSID, WEP key, and so on.
10	European CE Type Approval	CE should be approved for European market.
11	USA UL Type Approval	UL should be approved for USA market.
12	USA FCC Type Approval	FCC should be approved for USA market.
13	Canada CSA Type Approval	CSA should be approved for Canada market.
14	Korea MIC Type Approval	MIC should be approved for Korea market.
15	WiFi certification	WiFi should be certified for mutual compatibility.
16	RF power control	Fixed power and auto power should be supported.
17	DHCP, NAT	DHCP and NAT should be supported.
18	QoS	Voice packet should be handled with high priority. IEEE802.11e should be supported.

Registration

This phone is one of the iPECS phones recognized by the iPECS system. Therefore, your phone must be registered with the iPECS system for successful call processing.

The registration is accomplished in two phases; the first phase is Wireless LAN Connection, and the second is System Setting.

Wireless LAN Connection


SSID^{*1} is used as an identifier which means, "you are part of the 802.11b/g compliant wireless network". The phone should have the same SSID as the one configured within an AP. (See "Profile Settings" on page 89.)

*1 An SSID (Service Set Identifier) is the name of a wireless local area network.

Network

The phone can be a DHCP client or may be STATIC configured. (See "Profile Settings_steps 8. To set network to the default profile:" on page 89.)

System Setting

Enter the code to set the System Setting and press . The preset code is "0000" which could be changed by the user.

Direct Send / Remote Mode

These are configured as the phone's network status. (See "System Settings" on page 95.)

System IP

The phone must be programmed with the IP address of the iPECS system to initially request the registration.

Station Set

Depend on the system this station number could be set by manual.

Restarting the Phone

If something is not working right, restarting or resetting your phone to solve the problem. (See "Turning Your Phone On and Off" on page 16.)

Range

In a typical office environment where there are some obstacles, the WLAN coverage area is approximately 15 ~ 30 meters. A better coverage distance could be achieved in more open areas. The coverage area is, however, truly dependent on the office environment characteristics (e.g. construction material of walls, metallic objects, doors, windows, stair-wells, etc). Other radio equipment could also affect the coverage area. The coverage area will be unique for each office environment.

Signal Strength

Call quality depends on the signal strength in your area. The signal strength is indicated on the screen as the number of bars next to the Antenna icon. The more bars shown, the better the signal strength. If the phone is out of range of your access point, "Out of range" will be displayed on the screen. If you go out of access point range, the connection will be lost. When in range again, you can reconnect.

Access Point Probing

The phone has an ability to detect all reachable access points. Your phone's display shows a list of the SSIDs configured in the access points from which to choose (50 maximum).

To detect an access point:

- ▶ In standby mode, press navigation key **up** (⬆️) to search wireless LAN around your phone.
 - After a few seconds, the list of SSIDs configured in the access points are displayed. You can choose one of them under this preference.


Caller ID

Caller ID lets you know who is calling by displaying the number of the person calling when your phone rings.

Cleaning Phone

Use the soft cloth to gently wipe the display screen and the case.

To clean the phone:

- ▶ Unplug all cables, such as headset, power adapter and turn off the phone (press and hold ).
- To clean the metallic part of phone, such as charging contacts of charger and battery wipe them with a pencil eraser or cotton swab.
 - Avoid getting moisture in openings.
 - Clean the phone with a damp (not wet) cloth, or an antistatic wipe. Never use a dry cloth as this may cause a static shock.
 - Do not use window cleaner household cleaners, household polish, aerosol sprays, solvents, alcohol, ammonia, benzene, thinner, or abrasives to clean the phone as this will damage the product.

Phone's Menu

To view the Main Menu options, their respective submenus, refer to the follow table, it shows the available menu structure and indicates the number assigned to each menu option.

For more information about using phone's menu see "Navigating Through Menus and Options" on page 17.

1 Phone Book

1.1 Add New

1.2 Search Phonebook

1.3 Caller Groups

1.4 Speed Dials

1.5 Delete All

2 Sound

2.1 Alert By

2.2 Ring Tone

2.3 Ring Tone Volume

2.4 Power-on Tone

2.5 Power-off Tone

2.6 Key Tone

2.7 Key Tone Volume

2.8 Effect Sound

3 Display

3.1 Screen Theme

3.2 Greeting Note

3.3 Idle Clock

3.4 Dialing Font

3.5 Menu Style

3.6 Backlight

3.7 Font Type

3.8 Language

4 Call History

4.1 Call History

4.2 Call Duration

5 Messages

5.1 Write Message

5.2 Inbox

5.3 Outbox

5.4 Draft

5.5 Templates

6 Tools

6.1 Schedule

6.2 Memo

6.3 Alarm/Morning Call

6.4 Calculator

6.5 World Time

6.6 Timer

7 System

7.1 Forward

7.2 Conference

7.3 DND

7.4 MSG/CallBk

7.5 Flash

7.6 System Speed

7.7 System Redial

7.8 ICM

7.9 Mute

7.10 Transfer

7.11 Hold/Save

7.12 Program

8 Phone Setting

8.1 Profile Setting

8.2 System Setting

8.3 Codec Preference

8.4 Wireless LAN Setting



8.5 Security

8.6 Wireless LAN Status

8.7 Network Information


8.8 Phone Version





8.9 Reset Settings

While the phone is operating, the Antenna  and RSSI level  icon at the top of the screen shows whether you are in range of the WLAN area and can make and receive calls. The more RSSI levels mean the stronger signal and the call quality is good.

Making Calls

Dialing with a Phone Number


You can make a call to an internal (another user in your system) or to an external party by entering the number and pressing .

1. In standby mode,
2. Enter a phone number to connect a call and press the . If you make a mistake while dialing, press  to erase the numbers.
 - The phone  icon is shown on the display screen while trying to connect.
 - During the conversation, press the side volume key on the left side of the phone to control the volume level (from 0 to 10).
3. Press  to end an active call.
 - You can connect a provided headset to the phone. The headset has a microphone and mic button to answer a call, or end a phone call. (Refer to "Headset with Mic" on page 21 for more information.)

WARNING: When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety.



Dialing With a Finding Number

You can make a call after searching Phone Book and Call History for phone numbers that contain a specific string of numbers.



1. In standby mode,
2. Enter one or more digits. The more numbers you enter, the more specific the search becomes.
3. Scroll through a list of numbers to pick one and press .

Dialing From Phone Book

You can make a call from the Phone Book. If you have saved several numbers for an entry, select the desired number from the entry. (For more information see "Search Phonebook" on page 40.)






1. Press  > **Phone Book** > **Search Phonebook**, or from standby mode, press **Search** (right softkey) to access the Search Phonebook.
2. Select the entry you want to call and press  to dial the entry's default phone number.

or

To dial another number from the entry, select the name and press , and then select a number with which you wish to call and press .

Dialing From Call History

The Call History contains the numbers of up to 100 of the most recent calls you have made, received and missed.

1. In standby mode,
2. Press  to directly access the call list.
 - For phone calls, an additional icon appears giving information about the call.
 -  A call you made.
 -  A call you received.
 -  A missed call.
3. Scroll through the call list and select one.
4. Press  to make a call its number.

Dialing With Speed Dial

Each phone number stored in Phone Book is assigned a speed dial number, which you can use to call that number.

1. In standby mode,
2. Press and hold the speed dial number. The display confirms that the number has been dialed when it shows "Name and Number".
 - If you enter a number that is not associated to the speed dial, "No Speed Dial Num" message will display.

To use one digits dialing for speed dial locations 1 – 9:


- ▶ Press and hold the appropriate key for approximately two seconds.

To use two digits dialing for speed dial locations 10 – 99:

- ▶ Enter the first digit, and then press and hold the second digit for approximately two seconds.


Redialing the Last Number

This feature lets you redial the last number dialed from your phone.


1. In standby mode,
2. Press and hold . The last dialed number will automatically redial.
 - If the headset is plugged in, press and hold **Mic button** on the headset for about two seconds.


Dialing Options

When you enter numbers in standby mode, you will see a variety of dialing options displayed on the screen. To select an option, press the corresponding softkey.

- **Menu** to display the options.
- **Save** allows you to enter a number and save the phone number in your Phone Book.
- **Search** allows you to enter a digit or string of digits to display Phone Book entries that contain the entered numbers.
- Press  to dial the displayed phone number or the selected phone number.

Answering Calls




When the phone rings or vibrates, press . If the headset provided is plugged to the phone, you can also answer an incoming call by pressing the mic button on the headset when the ring sounds.

1. In standby mode,
2. Press , to answer an incoming call. Depending on your settings, you may also answer incoming calls by pressing any number key.
 - Your phone notifies you of incoming calls by any combination of ringing or vibrating, the backlight illuminating, or the screen displaying an incoming call message.
 - If the incoming call is from a number stored in your Phone Book, the entry's name is displayed. The caller's phone number may also be displayed, if available.
 - Caller Groups can be distinguished with a different ring type.
 - **Note:** Screen can display numbers with a maximum of 16 digits, so if the phone number (where the call was received) consist of more than 9 digits the call time is not displayed.



Ending a Call

When the conversation is over, press  to end an active call.

Or

1. Press **Menu** (left softkey) to display the options.
2. Select **End** and press .
 - The phone number will be saved to the call list. Press  to access the call list and then select an entry. Press  to save a number that is not in your Phone Book.

In Call Options

Press  during a call to display a list of available. To select an option, highlight it and press . The following options may be available:



- **End** to end a call.
- **Main menu** to display the main menu of some of the phone, such as Phone Book or Call List.

Using Quickly Change Mode

Activating Manner Mode (Quickly Set to Vibrate)

You can use the manner mode in public places.

To activate the manner mode quickly:

- ▶ From standby mode, activate the manner mode quickly by pressing  for 3 seconds. When the manner mode is set, the key tones are silent, and the phone is set to vibrate.
 - Manner mode is on, the  icon appears on the standby mode.
 - The phone remains in manner mode even if you turn it off and back on.




To release the manner mode:

- ▶ Press  for 3 seconds to switch into normal mode.



Activating Lock Mode

You can use the lock mode to prevent others from using your phone. When your phone is locked, you can only receive incoming calls or make calls to emergency number.





To activate the lock mode quickly:

1. From standby mode, press  within 3 seconds. "Lock mode on?" is displayed.
2. Select **Yes** to confirm and press , or select **No** to return to the previous menu.
 - When phone lock mode is enabled, the keypad will automatically lock on and the phone will prompt you to enter a security code.
 - Icon  and **LOCK STATUS** are displayed on the standby mode.

To release the temporary lock mode:

1. From standby, press  to choose **Unlock**.
 - Security Code window will pop up.
2. Enter your security code as it is a required field and then press .
 - However, the phone will automatically lock up again after 10 seconds unless you change lock phone setting to "Off".
 - If you release the lock mode permanently see "To release the permanent lock mode" on page 36.



To release the permanent lock mode:

1. After releasing the temporary lock mode.
2. Press  > **Settings** > **Security**.
2. Enter your security code as it is a required field and then press .
 - The preset code is “0000”, you can change it to the security code of your choice. (Refer to “Security” on page 97.)
3. Security sub-menus displayed, select **Lock phone** and then press .
4. Select **Off** to release permanently and press .

Using Keypad Lock (Keyguard)

You can use the keypad lock to prevent accidental keypresses, select menu. When the keyguard is on, calls may be possible to the official emergency number programmed into your phone.

To activate keypad lock:

- ▶ From standby mode, press  and hold it for about two seconds to lock the keypad.
 - To answer a call when the keypad lock is on, press the . When you end or reject the call, the keypad automatically locks.

To release keypad lock:









- ▶ Press  and hold it for about two seconds to unlock the keypad.




The Phone Book helps you stay in touch with the people by keeping track of all their contact information. This chapter explains how to use the Phone Book.

About Phone Book (Contacts)

This menu allows you to save and manage contact address information. The Phone Book option provides functions to add a new address, or to search saved contact addresses information by name, phone number and group.

A contact entry contains:

-  **Name** - A name is required when you are storing a number to the entry. Typically, this is the name of the person whose contact addresses information is stored in the entry.
-  **Personal Bell** - You can assign a ring tone to each entry. This is the sound your phone makes when you receive phone calls or call notifications from any of the numbers stored in the entry of your Phone Book.
- **Number(1)~(3)** - Each number must be assigned one of the following contact types to be used default number. After selecting a default to which you want to assign a number, the default number is used in direct dialing.
 -  **Mobile** - Mobile phone number for the entry.
 -  **Home** - Home phone number for the entry.
 -  **Office** - Office pnumber for the entry.
 -  **General** - General phone umber for the entry.
 -  **Pager** - Pager number for the entry.
 -  **Fax** - Fax number for the entry.





- You can enter or select an additional information for the entry, other information is optional:
 -  **E-mail** - E-mail address you assigned to the entry.
 -  **Group** - Group you assigned to the entry.
 -  **Memo** - Note, or other information that related to the entry.







Add New

This menu allows you to add a new contact address. You can enter contact address information that includes name, phone number, E-mail address, group information items, etc.

A name, number, and a contacts type are required for all contact entries. Other information is optional. You may enter the information in any order by scrolling through the entry details.




Creating a Contacts Entry

1. Press  > **Phone Book** > **Add New**.
2. To assign the name to the new entry:
 - Select **Name field** and enter the name.
 - The name of an contact entry can contain up to 32 characters.
 - Your phone can store up to 500 contacts, each entry can consist of one name, three different phone numbers.
3. To store a the number to the name:
 - Select **Number field** and enter the phone number being stored up to 32 digits.
4. To assign a contact type to the number:
 - Press **Menu** to select **Select Type** and press .
 - Press navigation key left or right to select a contact type Mobile, Home, Office, General, Pager, or Fax.
5. To assign more options to the number, proceed to steps 6 ~15. Otherwise, skip to step 15. Scroll down to additional fields and enter or edit information as desired.
6. To assign a speed dial to the number:
 - Press **Menu** to select **Speed dial** and press .
 - Select an available speed dial location and press .

7. To store an e-mail address to the number:
 - Select **E-mail field** and enter the e-mail address.
 - Press **Menu** (left softkey) to select an options .com, Symbol, Emoticon, or Cancel and then press .
8. To assign a group to the number:
 - Select **Group field** and select a group.
 - Press **List** (right softkey) to select an options No group, Family, Friends, Business, or School and then press .
9. To assign a personal bell to the number:
 - Select **Personal Bell field** and select a ring tone to assign to the entry so you can identify the caller by the ring tone.
 - Press **List** (right softkey). Use the navigation key to scroll through available ring tone and then press .
 - When you highlight a ring type, a sample ring tone will sound.
10. To store a memo to the number, select **Memo field** and compose a note, or other information, and then press .
11. When you are finished, press  to save the new contact entry.
 - If an entry has more than one number stored, you can assign default numbers to an contact entry.
 - Select a number you want to set as a default and press .

Storing Numbers Faster

To store numbers to Phone Book from standby mode:

1. Enter a phone number using the keypad.
2. Press  to store number.
3. Select one of the following options and press 
 - **Save new name** to store the number to a new entry.
 - **Add to name** to add an entry to store it to an existing entry.
4. With the contact type field highlighted, scroll left or right to select a contacts type.
5. To add more information to the entry, follow the applicable instructions in "Add New" on page 38.
6. Press  to save the contact entry.

Search Phonebook

This menu allows you to search your contact entries. Generally, the search operation is performed by entering a name in the field.

1. Press **☰** > **Phone Book** > **Search Phonebook**, or from standby mode, press **Search** (right softkey) to access the Search Phonebook.
2. Either highlight an entry or enter the first letter of a name in the Name field. You can find the name you entered or the nearest match.
or

Press **Menu** (left softkey) to display the options, select one of the following options and press **○**.

- **Search by Name** to find an entry by the name.
 - **Search by Contact** to find an entry by the number.
 - **Search by Group** to find an entry by the group.
3. If an entry has more than one number stored, contact type icons are displayed. Scroll left or right to view the icon for each number stored in the entry.
 4. Press **○** to display the entry, and then scroll up or down to view all information stored for the entry.

Adding a New Number to an Entry



1. Press **Search** (right softkey) to display a Phonebook entry.
2. Select an entry you wish to add a number to an existing entry and press **○**.
3. Press **Menu** (left softkey) to display the options.
4. Select **Edit** and press **○**.
5. Scroll down to the open number field, enter the new number and press **Type** (right softkey) to select a contact type, and then press **○**.
6. Press the navigation key left or right to select a contact type and press **○**.
7. Press **○** to save the new number.

or




To assign a speed dial number, select **Menu** > **Speed dial**. Complete the process, press **○** to change default numbers to an entry.

8. Select a number you want to set as a default and press **○**.

Editing an Entry

1. Press  > **Phone Book** > **Search Phonebook**.
2. Select an entry you wish to edit.
3. Press **Menu** (left softkey) to display the options.
4. Select **Edit** and press .
5. Follow the applicable instructions in "Add New" on page 38 to edit the entry.

Deleting an Entry





1. Press  > **Phone Book** > **Search Phonebook**.
2. Select an entry you wish to delete.
3. Press **Menu** (left softkey) to display the options.
4. Select **Delete** and press .
5. Select **Yes** to confirm and press .

Caller Groups

This menu allows you to manage group information. By default, there are 4 groups: family, friends, business, and school.

Assigning a Ring Tone to the Group

You can assign a ring tone for a caller group so the group ring tone sounds when a call from a specific contact address within that group arrives and there is no ring tone assigned for the contact address.

1. Press  > **Phone Book** > **Caller Groups**.
2. Select the group for which you wish to assign a ring tone.
3. Press **Menu** (left softkey) to display the options.
4. Select **Group ring tone** and press .
5. Scroll through the list of ring tones and select one. A sample ring tone will sound as you highlight each option.
6. Press  to assign the ring tone.
 - The ring icon  appears on the right side of the assigned group.
 - If the personal and group ring tone are assigned to the number at the same time, personal ring will sound when a call from that contact address.

Changing a Ring Tone

1. Press **☰** > **Phone Book** > **Caller Groups**.
2. Scroll to view ring tones assigned to the group and select one.
3. Press **Menu** (left softkey) to display the options.
4. Select **Modify melody** and press **ⓘ**.
5. Scroll through the list of ring tones and select one.
6. Press **ⓘ** to apply the ring tone.

Removing a Ring Tone from the Group

1. Press **☰** > **Phone Book** > **Caller Groups**.
2. Select the group from which you wish to remove a ring tone.
3. Press **Menu** (left softkey) to display the options.
4. Select **Unset melody** and press **ⓘ**.
5. Select **Yes** to confirm and press **ⓘ**.

Creating a Group

You can create up to 30 caller groups, and their names can be up to 16 characters long.

1. Press **☰** > **Phone Book** > **Caller Groups**.
2. Press **Menu** (left softkey) to display the options.
3. Select **Add** and press **ⓘ**.
4. To assign a name to the group, enter the caller group name using the keypad.
 - When you enter the group name, as soon as you see the text input rate on the top of the left side of the screen.
5. Press **ⓘ** to add a group.
 - If you do not assign a name, the screen will briefly show "Write group name".

Editing a Group

You can edit a group except for default groups.

1. Press **☰** > **Phone Book** > **Caller Groups**.
2. From the caller groups, select one.
3. Press **Menu** (left softkey) to display the options.
 - Press **Change** (right softkey) to directly access the edit mode.
4. Select **Edit** and press **ⓘ**.
5. To edit a name to the group, change the name using the keypad.
6. Press **ⓘ** to save.

Deleting a Group

You can delete a group except for default groups.

1. Press **☰** > **Phone Book** > **Caller Groups**.
2. Select a group you wish to delete.
3. Press **Menu** (left softkey) to display the options.
4. Select **Delete** and press **ⓘ**.
5. Select **Yes** to confirm and press **ⓘ**.
 - The numbers that existing in the group move to the No group when the group is deleted.

Adding Group Members

You can add group members that have a connect number to your group by selecting them from contact entries.

1. Press **☰** > **Phone Book** > **Caller Groups**.
2. From the caller groups, select one and press **ⓘ**.
3. Press **Add** (right softkey). If the group has more than one number stored, press **Menu** (left softkey) to display the options.
4. Select desired entry and press **ⓘ Add** (right softkey) again to save the group.
 - To deselect a entry, select it and press **ⓘ** to unselect.
 - A check mark **☑** appears next to each selected member.
 - Press **Menu** (left softkey) to display the options.

Excluding Group Members

You can exclude group members from the caller group.

1. Press **☰** > **Phone Book** > **Caller Groups**.
2. From the caller groups, select one and press **○**.
3. Select desired entry and press **Menu** (left softkey) to display the options.
4. Select **Exclude member** and press **○**.
5. Select **Yes** to confirm and press **○**.

Deleting Group Members

You can delete group members from the caller group, as well as the number will be deleted from the Phone Book.

1. Press **☰** > **Phone Book** > **Caller Groups**.
2. From the caller groups, select one and press **○**.
3. Select desired entry and press **Menu** (left softkey) to display the options.
4. Select **Delete** and press **○**.
 - The number may be deleted from the Phone book.
5. Select **Yes** to confirm and press **○**.

Speed Dials



Speed dialing allows you to make an outgoing call at a specific number by pressing either one or two key(s). Both the number and the associated key are to be registered in the "Speed Dials" option under the "Phone Book" menu.


Assigning a Speed Dial Number

Up to 99 phone numbers can be assigned to speed keys.

To assign a speed dial to an existing phone number:

1. Press **☰** > **Phone Book** > **Speed Dials**.
2. Press the navigation key down to scroll to the # [empty] and then select an available speed dial location.
3. Press **Add** (right softkey). A listing of your Phone Book entries will be displayed.

4. Select an entry for which you wish to assign a speed dial location.
 - If an entry has more than one number stored, press the navigation key left or right to select a contact type.
 - Only numbers in your Phone Book can be assigned as speed dial numbers.
 - If you attempt to assign an already associated phone number with a new speed dial location, "Already assigned" message will be displayed.
5. Press  to save the new speed dial number.
6. To view about the saved speed dial, press .






- Icon  shows the assigned speed dial number.

To assign a speed dial to a new phone number:

You can also assign speed dial numbers when you add a new entry, when you add a new phone number to an existing entry, or when you edit an existing number. (See related each page for more details.)

Moving a Speed Dial Number

You can move the already assigned phone number to a new speed dial location.

1. Press  > **Phone Book** > **Speed Dials**.
2. Select a speed dial number you wish to move.
3. Press **Option** (left softkey) to display the options.
4. Select **Move** and press .
5. Scroll up or down to find an desired speed dial number and select one.
6. Press  to apply the new speed dial number.

Changing a Speed Dial Number

You can change an already in use speed dial location to a new phone number.

1. Press **☰** > **Phone Book** > **Speed Dials**.
2. Select a speed dial number you wish to change.
3. Press **Option** (left softkey) to display the options.
4. Select **Change** and press **ⓘ**.
5. Select **Yes** to confirm and press **ⓘ**.
6. Scroll up or down to find an desired entry and select one.
7. Press **ⓘ** to apply the new speed dial number.

Removing a Speed Dial Number

You can remove assigned speed dial to a phone number either each one or all of them at once.

1. Press **☰** > **Phone Book** > **Speed Dials**.
2. Select a speed dial number you wish to remove.
3. Press **Option** (left softkey) to display the options.
4. Select **Remove speed dial** and press **ⓘ**.
 - If you select **Remove all**, all assigned speed dial number can be deleted at once.
5. Select **Yes** to confirm and press **ⓘ**.

Delete All

To delete all entries:

1. Press **☰** > **Phone Book** > **Delete all**.
2. Select **Delete all** and press **ⓘ**.
3. Select **Yes** to delete all saved entries from Phone Book and press **ⓘ**.

This menu allows you to customize your phone to sound just the way you want it to. Your phone provides a variety of ringer options that allow you to set your ring, volume, or effect sound. This chapter describes how to change your phone's sound setting to best suit your needs.

Alert By

You can set your phone to alert when you receive a call.

1. Press **[-]** > **Sound** > **Alert by**.
2. Scroll through the list of alert types and select one. A alert will sound or vibrate as you highlight.
3. Press **[O]** to assign the current ringer.
 - Standby mode will display alert indicator depending on which mode the alert is currently in. (Refer to "Status Icons" on page 10.)
 - The vibration option allows you to be notified of calls with a vibration instead of an audible alert.





Ring Tone

You can set the ring tone to identify for incoming call. The phone supports 5 different ring tone category, each with several ring tones under each category.

1. Press **[-]** > **Sound** > **Ring Tone**.
2. Select a category and press **[O]**.
3. Use the navigation key to scroll through the ring tone. A ring tone will sound as you highlight each option.
4. Press **[O]** to assign a ring tone.




Ring Tone Volume

You can adjust the volume settings to suit your needs and your environment.

1. Press  > **Sound** > **Ring Tone Volume**.
2. Using the navigation key, choose a volume level and press .
 - The volume level is set at , you will not hear any ring tone when you receive a call regardless of the ring tone you have set.
 - Icon  will display in standby mode.




Power-On Tone

You can set the "switch -on" effect that sounds when the phone is turned on.

1. Press  > **Sound** > **Power-on Tone**.
2. Select a category and press .
3. Use the navigation key to scroll through the power-on tone. A power-on tone will sound as you highlight each option.
 - **No sound** allows you to mute turning your phone on.
 - **Set Default** directly set a power-on tone to default.
4. Press  to assign a power-on tone.

Power-Off Tone

You can set the "switch -off" effect that sounds when the phone is turned off.

1. Press  > **Sound** > **Power-off Tone**.
2. Select a category and press .
3. Use the navigation key to scroll through the power-off tone. A power-off tone will sound as you highlight each option.
 - **No sound** allows you to mute turning your phone off.
 - **Set Default** directly set a power-off tone to default.
4. Press  to assign a power-off tone.

Key Tone

You can set the key tone that sounds when a key is pressed.

1. Press **[Menu]** > **Sound** > **Key Tone**.
2. Using the navigation key, select a key tone and press **[Enter]**.
 - **No sound** will not make key tone when you press keys.

Key Tone Volume

You can adjust the volume of the keypad tone.

1. Press **[Menu]** > **Sound** > **Key Tone Volume**.
2. Using the navigation key, choose a volume level and press **[Enter]**.
 - The volume level is set at **[Mute]**, you will not hear any keypad tone when you press keys regardless of the key tone you have set.
 - **Tip:** You can adjust the key tone volume in standby mode by using the side volume key on the left side of the phone.

Effect Sound

You can set the confirmation tone that sounds when a function is set.

1. Press **[Menu]** > **Sound** > **Effect Sound**.
2. Select **Yes** to confirm or **No** to cancel, and then press **[Enter]**.
 - If you choose "No", you will not hear any confirmation tone that notify you the function is set.

This menu allows you to customize your phone to look just the way you want it to. This chapter describes how to change your phone's display setting to best suit your needs.

Screen Theme

You can choose what you see on the display screen when in standby mode. The phone provides twenty screen themes, including analog clock mode.

1. Press **⏏** > **Display** > **Screen Theme**.
2. Use the navigation key to scroll through the image and select one.



File name field

- The name field shows you file name.
3. Press **⏏** to assign an image.
 - If you choose an Analog, the current time will be displayed on the screen in analog mode.

Greeting Note

You can set your own custom greeting to display on the screen in standby mode.

1. Press **[-]** > **Display** > **Greeting Note**.
2. Select one of the following options and press **[O]**.



Change text input mode

- **On** to show the greeting, enter a custom greeting up to 50 characters long. (See "Entering Text" on page 18.)
- **Off** to disable a greeting.

Idle Clock

You can select a type and color for the idle clock to be displayed when in standby mode.

1. Press **[-]** > **Display** > **Idle Clock**.
2. Using the navigation key, select a clock type and color for the idle clock.
 - **Small or Large** to show the idle clock, If you choose "Small or Large", you can set the color using the color chart.
 - **Clock Off** to disable the idle clock .
3. Press **[O]** to apply the setting.

Dialing Font

You can choose the dialing font and color when enter number (for example, when dialing or pre-dialing).

1. Press **[-]** > **Display** > **Dialing Font**.
2. Using the navigation key, select a font size and color with which the number will display on the screen.
3. Press **[O]** to apply the setting.

Menu Style

You can choose how your phone's menu is displayed in either a list style or a grid style on the screen.

1. Press **[-]** > **Display** > **Menu Style**.
2. Select one of the following options and press **[O]**.
 - **List menu** to display the menu as a list.
 - **Grid menu** to view the menu as a grid.

Backlight

You can select how long the display screen and keypad remain backlight after any keypress is made, including a screen brightness control.

1. Press **[-]** > **Display** > **Backlight**.
2. Select one of the following options and press **[O]**.

Following table shows the backlight time length and display screen brightness.

Item	Default value
Standard	- LCD duration: 10 sec - LCD brightness: Brightest
Saving	- LCD duration: 5 sec - LCD brightness: Bright
Ultra Saving	- LCD duration: 5 sec - LCD brightness: Normal
User Settings	- LCD duration: 5 sec, 10 sec, 20 sec, 30 sec, 1min, or 3min - LCD brightness: Normal, Bright, or Brightest

Note: Long backlight settings, such as "3Min" and "Brightest" reduce the battery's talk and standby times.



Font Type

You can choose the font type to display your phone's screen.

1. Press **[-]** > **Display** > **Font Type**.
2. Select the font you want to use and press **[O]**.

Language

You can set the language to use for displaying messages and menus.




1. Press  > **Display** > **Language**.
2. Select the language available in the language list and press .
 - Currently supported languages are 6 Languages: Korean, English, Spanish, Italian, German and Turkish.

The call history keeps track of all calls. This chapter guides you through accessing and making the most of your call history.


Call History

The call history is a list of the last 100 phone numbers for calls you have dialed, received, or missed. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.



If the number of a call history is stored in phone book, the following information appears:

- The name assigned to the number.
- The contact type icon appears giving information about the call.
 -  **A Dialed call:** Indicates outgoing calls made from your phone.
 -  **A Received call:** Indicates received calls that were answered.
 -  **A Missed call:** Indicates missed calls.


Viewing Call History


In standby mode, press  to directly access the call history.

Or

1. Press  > **Call History** > **Call History**.
2. Select **Missed Calls**, **Received Calls**, **Dialed Calls** or **All Calls**.
 - Selecting "All Calls" will allow you to view the call history for all types of calls.
3. Scroll through the list and select one.
4. Press  to view the details of an entry.

Call History Options

Select an entry and press  to display the date and time of the call, the phone number, and the caller's name (if the number is already in your phonebook). Press **Menu** (left softkey) to display the following options:






- **Save New Name** to save the number to the phone book. (It could be visible if it is not already in your phone book.)
- **Add to Name** to add the number to an existing phone book.
- **Send Message** to send a message to the selected entry.
- **Delete** to delete the entry.
- **DeleteAll** to delete all calls entries.

Note: You can also view the next or previous call history entry by pressing the navigation key left or right.

Making a Call From Call History


If you need to make a call from the calls history.

1. Press  > **Call History** > **Call History**.
2. Select one of the following call history type and press .
 - **Missed Calls** contain any missed calls.
 - **Received Calls** contain any received calls that were answered.
 - **Dialed Calls** contain all outgoing calls made from your phone.
 - **All Calls** contain all type of the call.
3. Select an entry to make a call its number and press .


Call Duration

This menu allows you to view or reset the cumulative call time by time since start use.

Viewing Call Duration

1. Press  > **Call History** > **Call Duration**.
2. Select an option to view the cumulative call time.
 - When you select call option to view its details, you see all the length of cumulative time the calls.

Resetting Call Duration


1. You can also reset a call duration by pressing **Reset** (right softkey) after step 2 above.
2. If you are certain you want to erase the call duration, select **Yes**.
 - Enter your password as it is a required field and then press .
 - The preset code is "0000", you can change it to the password of your choice. (Refer to "Security" on page 97.)

or

Select **No** to cancel and return to the previous menu.



With Messages, you can send and receive short text messages between your phone and another phone that has been registered with in the iPECS system. This chapter explains how to use the Messages.


Viewing Message

When you receive a text message, your phone notifies you with the icon  at the top of your screen.

In standby mode, press navigation key right to directly access the Messages.

Or

1. Press  > **Messages** > **Inbox**.
2. Select the message you want to view and press .
3. After reading the message, select the one of following options you want:




- **Menu** to display the options which are available in the message. (See "Inbox" on page 61.)
- **OK** to go to the standby mode.
- **Delete** to delete the current message.


Writing Text Message


Compose a text message you wish to send it. A single text message can be up to 80 characters.

1. Press **[-]** > **Messages** > **Write Message**.
2. Select **Contact me** field (It may already be highlighted.) to compose a message. When writing a message you can use the common terms or smiley (emoticons) and press **[OK]**.









- To type a message, use your keypad to enter your message. Use the right softkey to select a character input mode. (See "Entering Text" on page 18.)
 - To use a common terms or a smiley, press the **Menu** (left softkey), select **Common Terms** or **Smiley**, and then highlight your desired message or emoticon and press **[OK]**. (For more information on common terms, please see "Templates" on page 63.)
3. Use the keypad to enter the number you wish to send a message or press **Menu** (left softkey) to select the entry method you prefer:
 - **Recent SMS Num.** to select from a list of recent message recipients.
 - **Search Phonebook** to select a recipient from your Phonebook.
 4. If you wish to save the current message, press navigation key left or right to select **Save** or press **Menu** (left softkey) to select one of the following options and press **[OK]**.




- **Save to draftbox** to save a message as a draft.
 - **Save option** to select the option you prefer:
 - **Save** message will automatically be saved in the Outbox.
 - **Not save** message was sent but not saved in the Outbox.
5. Press  to send the message.

Inbox

The icon  on your phone's screen will remain on until there are no unread items in the Inbox.

1. Press  > **Messages** > **Inbox**.
2. Select the message you want to view and press .
 -  indicates unread text messages.
 -  indicates that you have read messages.
 - Inbox shows all of your messages. Once a message is displayed, you can use your navigation key to view the other messages.
3. Press **Menu** (left softkey) to select one of the following options and press .




- **Reply** to reply to the recipients on the selected message. (Follow steps under "Writing Text Message" on page 61 to complete and send your reply.)
- **Forward** to forward the selected message to another party.
- **Keep** to protect the message cannot be deleted.
- **Save Address** to add the number which you wish to save to the Phonebook. (See "Add New" on page 38.)
- **Save number** to get the number which was written in text message and save it to phonebook.
- **Delete** to delete the selected messages.

Outbox

Any message sent from your phone is stored in the Outbox.

1. Press **[-]** > **Messages** > **Outbox**.
2. Select the message you want to view and press **[O]**.
3. Press **Menu** (left softkey) to select one of the following options and press **[O]**.




- **Forward** to send the selected message to another party.
- **Edit** to edit message you want to change.
- **Keep** to protect the message cannot be deleted.
- **Delete** to delete the selected messages.

Draft

While you are creating a message, you can save it in Drafts before you send. The draft messages are listed with the date of when the messages were saved.

1. Press **[-]** > **Messages** > **Draft**.
2. Select message you want to view.
3. Press **Menu** (left softkey) to select one of the following options and press **[O]**.



- **Write Message** to compose a text message.
- **Keep Message** to protect the message cannot be deleted.
- **Delete** to delete the selected messages.
- **Multiple Delete** to delete many messages at once.
- **Delete All** to delete all messages.

Templates

There are four preset messages to help make sending text messages easier. Customize or delete these messages to suit your needs, or add your own messages to the list.

Editing or Deleting a Preset Message

1. Press **☰** > **Messages** > **Templates**.
2. Select the message you want to edit or delete and press **⊙**.
3. Press **Menu** (left softkey) to display the options.
4. Select **Edit** and press **⊙**.
 - Edit the selected message (see "Entering Text" on page 18) and press **⊙**.
 - or
5. Select **Delete** and press **⊙**.
 - Select **Yes** to delete the selected message. (Select **No** to cancel the deletion.)

Adding a New Preset Message


1. Press **☰** > **Messages** > **Templates**.
2. Press **Add** (right softkey) to add a new message.
3. Compose your own preset message and press **⊙**.
 - Your new preset message will be added to the end of the list.



Your phone is equipped with several personal information management features that help you manage your time efficiently. This chapter shows you how to use these features that helps you.

Schedule

The Scheduler keeps your event convenient and easy to access. Simply store your events and your phone alerts you with a reminder of your event.











In the calendar view, If you have events stored for the selected day, they will be highlighted in a different color as follows:



- **18** indicates a user specified holiday has been set.
- **21** indicates a schedule or anniversary have been set. The following icons are used to show the types of events saved to the date.
 -  means a schedule and shows its number.
 -  means an anniversary and shows its number.


Viewing an Events



You can view the schedule by the month and also view the details of each event.

1. Press  > **Tools** > **Schedule**.
2. Select the day for which you would like to view events and press .
 - Initially, the cursor  appears on today's date according to the phone settings.
 - Numbers in blue indicate Saturdays, in red indicates Sundays and holidays, and scarlet indicate the user specified holiday.
3. Select an event to view its details and press .
 - If you have up to 2 events scheduled for the day, they will be listed in chronological order.
 - You can also view the next or previous day's events by pressing the navigation key left or right.
4. The schedule event contains:
 -  **Time** - The time for the event.
 -  **Subject** - The name you assigned to the event.
 -  **Type** - The type you saved in the event.
 -  **Repeat** - For recurring the event.
 -  **Reminder** - The scheduled alert for the event that include a start time.
 -  **Alarm** - The ring tone for the reminder.

Adding an Event

Schedule event must have a subject and be stored to a date. Other information is optional.





1. Press  > **Tools** > **Schedule**.
2. Using the navigation key, select the day to which you would like to add an event and **Add** (right softkey)
3. Select a time for the event by highlighting the time field.
 - Using the keypad or navigation key, enter the start and end times for the event
 - The time is based on a 12-hour format, press right softkey to select either "am" or "pm".

4. Enter a title for the event by highlighting the **Subject**.
 - Enter the event title and press . (See "Entering Text" on page 18.)
 - Event title must be entered to be saved to a date.
5. Choose a type for the event by highlighting the type field.
 - Press the navigation key left or right to choose Schedule or Anniversary.
6. Select a repeating status for the event by highlighting the repeat field.
 - Press the navigation key left or right to select Once, Daily, Weekly, Monthly, Yearly, or Yearly(Lunar).
7. Select an alarm time for the event by highlighting the alarm field.
 - Press the navigation key left or right to select No Alarm, On Time, Before 15m, Before 30m, Before 1hr, Before 1day, Before 3day, Before 1W.
8. Select a ringer type for the alarm by highlighting the ringer field.
 - Use the navigation key to scroll through available alarm tones.
9. Press  to store the event.

Deleting an Event

In the monthly calendar, days with events scheduled are highlighted.



To delete past events:


1. Press  > **Tools** > **Schedule**.
2. Press **Menu** (left softkey) to display the options.
3. Select **Delete** and press .
4. Select **Delete Past** to delete all past occurrences of the event and press .
5. Select **Yes** to confirm and press .


or

Select **No** to return to the previous menu.

To delete multiple events:





1. Press  > **Tools** > **Schedule**.
2. Press **Menu** (left softkey) to display the options.
3. Select **Delete** and press .

4. Select **Multiple Delete** to delete an event through the specified period of time and press .
5. Using the keypad, enter the date for the duration by highlighting the date field.







6. Press  to delete events.

To delete all events:

1. Press  > **Tools** > **Schedule**.
2. Press **Menu** (left softkey) to display the options.
3. Select **Delete** and press .
4. Select **Delete All** to delete all occurrences of the event and press .
5. Select **Yes** to confirm and press , or select **No** to return to the previous menu.

Setting your Holiday

You can assign any of the days of the week to particular holiday.

1. Press  > **Tools** > **Schedule**.
2. Using the navigation key, select the day to which you would like to assign a holiday.
3. Press **Menu** (left softkey) to display the options.
4. Select **Holiday** and press .
5. Select an holiday option and press .
 - Press the navigation key up or down to select On the day, Weekly, Monthly, Yearly, and Mutple Settings.
6. If you select Mutple Settings, enter a number for holiday by using the keypad and press .
 - The date corresponding to the assigned holiday is represented "in scarlet" in the monthly schedule management screen.

Searching an Event


You can find an event which you would like to view by entering the title of event.

1. Press **[-]** > **Tools** > **Schedule**.
2. Press **Menu** (left softkey) to display the options.
3. Select **Search** and press **[O]**.
4. Enter a title for searching and select a type of event and press **[O]**.
 - Press the navigation key left or right to select **Schedule**, **Anniversary**, or **All**.

Moving to a Specific Event

You can go directly to the date of the event in order to view it at once.

1. Press **[-]** > **Tools** > **Schedule**.
2. Press **Menu** (left softkey) to display the options.
3. Select **Go to Date** and press **[O]**.
4. Enter a date which you would like to move to and press **[O]**.



- The cursor **[]** will then move to the specified date.

Going to Today

You can go to today's date, while navigating the schedule.

1. Press **[-]** > **Tools** > **Schedule**.
2. Press **Menu** (left softkey) to display the options.
3. Select **Today** and press **[O]**.
 - The cursor **[]** will then move to today's date.

Memo

Your phone comes with a notepad that you can compose a note of up to 180 characters, and store up to 30 memos.

Composing a Memo

1. Press **[-]** > **Tools** > **Memo**, or from standby mode, press the navigation key down to directly access the Memo.
2. Press **Menu** (left softkey) to display the options.
3. Select **Add** and press **[O]**.
4. Type a memo using the keypad and press **[O]**. When entering text for the memo, you may want to press **Menu** (left softkey) to display one of the following options:
 - **Template** to use a template with a prepared message, such as "Please Call me back!", or "I'm late. I will be there at."
 - **Symbol** to apply to your text, press the appropriate key indicated on the display.




Reading a Saved Memo

1. Press **[-]** > **Tools** > **Memo**, or from standby mode, press the navigation key down to directly access the Memo.
2. The list of saved memos will be displayed. Scroll through the list and select one.
3. Press **[O]** to display a memo details.
4. While reading the memo if you want to read other one, press **[O]** return to the previous menu and select a memo.

Deleting a Memo

1. Press **[-]** > **Tools** > **Memo**.
2. The list of saved memos will be displayed. Scroll through the list and select one.
3. Press **Menu** (left softkey) to display the options.
4. Select **Delete** and press **[O]**.
5. Select **Yes** to delete the selected memo from the list and press **[O]**.
or
Select **No** to return to the previous menu.








Deleting All Memo

1. Press  > **Tools** > **Memo**.
 2. Press **Menu** (left softkey) to display the options.
 3. Select **Delete All** and press .
 4. Select **Yes** to delete all saved memo and press .
- or
- Select **No** to return to the previous menu.

Alarm Clock


Your phone comes with a built-in alarm clock that has multiple alarm capabilities.




Viewing an Alarm

1. Press  > **Tools** > **Alarm/Morning Call**, or from standby mode, press the navigation key left to directly access the Alarm.
2. The list of saved alarm clocks will be displayed. Scroll through the list and select one.
3. Press  to display an alarm details.
4. The alarm clock contains:
 -  **Time** - The time for the alarm.
 -  **Repeat** - For recurring the alarm.
 -  **Ring** - The ring tone for the alarm.
 -  **Memo** - The title you assigned to the alarm.
 -  **Indicator** - The indicator for the alarm setting.



Setting an Alarm

You can set a time for the alarm including its title.




1. Press  > **Tools** > **Alarm/Morning Call**.
2. Press the **New** (right softkey) to add a new alarm.
3. Select a time for the alarm by highlighting the time field.
 - Using the keypad, set the alarm time and press right softkey to select either "**am**" or "**pm**".
4. Select a repeating status for the alarm by highlighting the repeat field.

- Press the navigation key left or right to select Once, Mon~Wed, Mon~Fri, Mon~Sat, Except holiday, and Everyday.
5. Select a ring type for the alarm by highlighting the ring field.
 - Use the navigation key to scroll through available alarm ring.
 6. Enter a title for the alarm by highlighting the **Memo**.
 - Enter the alarm title and press . (See "Entering Text" on page 18.)
 7. Turn the alarm on or off by highlighting the activation field.
 - Press the navigation key left or right to select On or Off.
 8. Press  to set the alarm.
 - Icon  is displayed in standby mode indicates that alarm is set.
 - During a voice call, the alarm works in vibration mode.

Editing an Alarm

1. Press  > **Tools** > **Alarm/Morning Call**.
2. The list of saved alarms will be displayed. Scroll through the list and select one.
3. Press **Menu** (left softkey) to display the options.
4. Select **Edit** and press .
5. Follow the applicable instructions in "Setting an Alarm" on page 75 to edit the alarm.

Deleting an Alarm



1. Press  > **Tools** > **Alarm/Morning Call**.
2. The list of saved alarms will be displayed. Scroll through the list and select one.
3. Press **Menu** (left softkey) to display the options.
4. Select **Delete** and press .
5. Select **Yes** to delete the selected alarm from the list and press .

or

Select **No** to return to the previous menu.






Deleting All Alarm

1. Press  > **Tools** > **Alarm/Morning Call**.
2. Press **Menu** (left softkey) to display the options.

3. Select **Delete All** and press .
 4. Select **Yes** to delete all saved alarm from the list and press .
- or
- Select **No** to return to the previous menu.


Calculator


Your phone comes with a built in calculator that has limited accuracy for simple calculations, such as add, subtract, multiply, and divide.

1. Press  > **Tools** > **Calculator**.
2. To make a calculation:
 - Enter the first number of the calculation, if you want to remove a number, press .
 - Press  (left softkey) to enter decimal points.
 - Press  to change the numeric value from positive to negative.
 - Select a mathematical functions (+, -, ×, or ÷).
 - Enter the second number and press  for the total.

World Time

You can view the time in over 50 different locations.

1. Press  > **Tools** > **World Time**.
2. Press **Home** (right softkey) to select a city to be assigned the home (the local area in which you live).
3. Press the navigation key left or right to scroll through different time zones.



Indicates your local area

- The time zones will be shown a time difference between two cities based on your local area.

Timer

The timer can be used for various calendrical calculations.

Using the D-Day Finder

You can calculate what date it will be in a number of days after a particular date.

1. Press **[-]** > **Tools** > **Timer**.
2. Select **D-day Finder** and press **[O]**.
3. Enter date from and add a number of days to calculate a future date and press **[O]** to get the result.
4. Press **Reset** (left softkey) to set the finder back to zero.

Using the D-Day Counter

You can use d-day counter to refer to the day that is chosen for the beginning of an important event.

To set a D-day counter:


1. Press **[-]** > **Tools** > **Timer**.
2. Select **D-day Counter** and press **[O]**.
3. Press **Add** (right softkey).
4. Enter a title for an upcoming event by highlighting title field.
 - Enter the event counter title. (See "Entering Text" on page 18.)
5. Select a d-day for the event counter by highlighting the time field.
6. Press **[O]** to save the counter.

To view a D-day counter:





1. Press **[-]** > **Tools** > **Timer**.
2. Select **D-day Counter** and press **[O]**.
3. The list of saved counters will be displayed. Scroll through the list and select one.
4. Read the information about the counter.

To edit a D-day counter:





1. Press **[-]** > **Tools** > **Timer**.
2. Select **D-day Counter** and press **[O]**.

3. The list of saved counters will be displayed. Scroll through the list and select one.
4. Press **Menu** (left softkey) to display the options.
5. Select **Edit** and press .
6. Follow the applicable instructions in "To set the D-day counter" to edit the D-day counter.

To delete a D-day counter:



1. Press  > **Tools** > **Timer**.
 2. Select **D-day Counter** and press .
 3. The list of saved counters will be displayed. Scroll through the list and select one.
 4. Press **Menu** (left softkey) to display the options.
 5. Select **Delete** and press .
 6. Select **Yes** to delete the selected counter from the list and press .
- or
- Select **No** to return to the previous menu.


To delete All D-day counter:

1. Press  > **Tools** > **Timer**.
 2. Select **D-day Counter** and press .
 3. Press **Menu** (left softkey) to display the options.
 4. Select **Delete All** and press .
 5. Select **Yes** to delete all saved counter from the list and press .
- or
- Select **No** to return to the previous menu.

Using the Stopwatch

Your phone comes with a built in stopwatch.

1. Press  > **Tools** > **Timer**.
2. Select **Stopwatch** and press .
3. To use a Stopwatch:



- Press **Go** (OK key) to start the stopwatch.
- Press **Lap** (left softkey) to make a lap time of up to 6.
- Press **Stop** (OK key) to pause the stopwatch.
- Press **Reset** (right softkey) to reset the stopwatch to zero.

This chapter explains how to use the System feature which can be synchronized with iPECS System.

Note: Any of these features do not work on your phone, please contact your system administrator or refer to the iPECS System Manual for details.

Call Forward


Use the Call Forward features to redirect incoming calls from your phone to another number. The types of Call Forwarding are:


- **Unconditional (U)** Forward all incoming calls to another number.
- **Busy (B)** Forward while your phone is busy.
- **No Answer (N)** Forward when your phone is not answered after a certain amount of time delay.
- **Busy/ No Answer (BN)** Forward while the phone is busy, and all calls forward when not answered.

A call already on your phone and recall cannot be forwarded.

Activating Call Forward

1. Press **[*]** > **System** > **Forward**.
2. Select the type of call forward by entering a call forwarding code (1~4). In iPECS-LIK, the codes of call forwarding are below:





- **Code 0: Remote Call Forward**, enable call forward for your phone from a different phone. It may need to enter your Authorization Code.
 - **Code 1: Unconditional**, refer to page 77.
 - **Code 2: Busy**, refer to page 77.
 - **Code 3: No Answer**, refer to page 77.
 - **Code 4: Busy/ No Answer**, refer to page 77.
 - **Code 5: Attendant Off-Premise**, forward ncoming CO calls to an outside number. It is not supported on WIT-400HE.
3. Enter the phone number (Internal, Internal Groups Number etc.) to which you want to calls forwarded and press .



- You will see a system message informing you that call forwarding is activated. For example, **Unconditional** to the phone number **104**, "FWD104(U)" displays on the screen in standby mode. '■' appears next to the function in the menu list.
- **Note:** When call forwarding is activated, you will not be able to answer calls in your phone, as they will only ring at the forwarding number.

Deactivating Call Forward

1. Press  > **System** > **Forward**.
2. Press  to disable Call Forward.




- When the function is released, '■' disappears.

3-Party Conference

The phone supports conferencing with two other parties. The number of person supported in a conference call depends on the System. You can do more than a three person conference call with a Multi-Party Conference Interface Module (MCIM).


Setting up a Conference Call

1. During a first call, press navigation key left to select **System > Conference**.




- The first call is on hold and dial tone is heard.
2. Dial the second party for the conference, and press navigation key left to select **System > Conference** when the party answers.




- For joining multiple person in a conference, repeat steps 1~2 .
3. Select **System > Conference** and press  to connect all parties.

Ending up a Conference Call

When the conversation is over, press  to end a conference and disconnect all parties.

or

1. Press **Menu** (left softkey) to display the options.
2. Select **End** and press .

DND (Do Not Disturb)

When the DND (Do Not Disturb) feature is activated, the phone will not notify you of an incoming call thus allowing you to work without interruptions from incoming calls. Depending on the system the caller will get the busy tone or voice announcement.

Activating DND

1. Press **[-]** > **System** > **DND**.
2. Press **[On]** to enable DND.



- When the function is set, "DO NOT DISTURB" displays on the screen in standby.

Deactivating DND

1. Press **[-]** > **System** > **DND**.
2. Press **[Off]** to disable DND.

Message Waiting/Call Back

These functions can be used for internal calls when the called party is busy, no answer or in DND (Do Not Disturb).


Message Waiting


Message waiting allows you to send a message to internal number asking them to call you.


To send a message:


1. If the called party does not answer.
2. Press navigation key left to select **System** > **MSG/CallBk** and press **[On]**.
 - When choose MSG/CallBk, at this point the call is terminated and return to the standby mode.

To review/call back a message:

When you receive a message, your phone notifies you with the icon  at the top of phone's screen.

1. In standby mode, press navigation key left to access the **System** > **MSG/CallBk** and press .



- For example, "M: 104" means that this message has been sent from internal number 104.
2. Press the navigation key left to select the **System** > **MSG/CallBk**.
 3. When 'M' blinking, press  to be connected to dial tone and then place the call.


Call Back

Call Back allows you to reserve the call when a busy party becomes available.

To reserve a call back:

1. If the called party is busy.
2. Press navigation key left to select **System** > **MSG/CallBk**.
 - When choose MSG/CallBk, at this point the call is terminated and return to the standby mode.

To answer a call back:

1. When the called party becomes free, the system will call you back.
2. Press  to answer an Call Back call, the called party's phone will ring and your call will be connected.
 - A Call Back will be canceled if not answered within a certain amount of time (set by your system administrator).

Flash



The Flash function allows you to dial while busy tone is heard or to make another call without press  to end a current call.


1. If the called party is busy.
2. Press navigation key left to select **System > Flash**.
2. When dial tone is heard, enter the phone number to which you want to call again.

System Speed

You may program frequently dialed external number of your choice and store them in Speed Dial location on your phone. Internal number cannot be stored in speed dial.


Storing a Speed Dial


1. Press  to access programming mode.
2. Press navigation key left to select **System > System Speed** and press .
3. Enter the Speed Dial location with the number which can be up to 2 or 3 digits long, you want to store.





- The screen will show "ENTER SPD (XX)" to prompt you to enter the Speed Dial location number where required.
- Assigned Speed Dial number for your phone may differ depending on what system you have used. In iPECS-LIK, the Speed Dial number are:
 - LIK 50/100: 00 ~ 19
 - LIK 300: 000 ~ 099


3. Enter the CO Code. Normally the CO code is '9' or '0' etc. For more information on this, please ask your system administrator.



- For example, "SPEED 01" means that the number of location in the Speed Dial you entered.
4. Enter a phone number to the Speed Dial location 01 and press  to save the location.



5. Enter a name to the number using the keypad and press  to save the name.




- You can enter alphanumeric characters using the phone's keypad supported the text input mode are ABC or 123 referring to "Character Input Table" on page 85.
 - The name of an Speed Dial can contain up to 16 characters.
6. Repeat steps 2~5 for each Speed Dial you want to add.


Using a Speed Dial


You can make a call using Speed Dial in the phone.






To make a call using Speed Dial location number:

1. Press navigation key left to select **System > System Speed** and press .
2. Press the Speed Dial location number using the keypad. The following are number of Speed Dial for your reference:
 - Personal programming Speed Dial
 - LIK 50/100: 00 ~ 19
 - LIK 300: 000 ~ 099
 - System Speed Dial
 - LIK 50/100: 200 ~ 999
 - LIK 300: 2000 ~ 4999
3. Your phone automatically place the call.

To make a call after viewing the name:

1. Repeat above steps 1~2.
2. Press navigation key left to select **System > System Speed** and press .



- "DIAL BY NAME" is displayed along with informing the Code as below.
 - **I: 1 "I"** means the Internal number's name, press  to view.
 - **US: 2 "US"** means the User Speed Dial, press  to select.
 - **SS: 3 "SS"** means the System Speed Dial, press  to select.
3. Press navigation key up or down to scroll through the Speed Dial.
 4. When the desired number is displayed then press  to dial.
 - You can also view the number of selected name, by pressing .

Deleting a Speed Dial

You can delete an existing Speed Dial in the phone.

1. Press to access programming mode.
2. Press navigation key left to select **System** > **System Speed** and press .
3. Enter the Speed Dial location with the number you want to delete.
 - For example, if you want to delete Speed Dial 01, Press "0" and "1" using the keypad.
4. When displaying the number of Speed Dial, press navigation key left to select **System** > **System Speed** and press .

Character Input Table


The following table describes how to enter each letter and number. For example, to enter the "Q" press twice.


Letter	Keypad	Letter	Keypad	Letter	Keypad
Q		A		D	
Z		B		E	
.		C		F	
1		2		3	
G		J		M	
H		K		N	
I		L		O	
4		5		6	
P		T		W	
R		U		X	
S		V		Y	
Q		8		Z	
7				9	
Blank		0			
:					
,					

System Redial

This feature allows you to redial the last number that you dialed from your phone.



1. Press navigation key left to select **System > System Redial** and press .



2. Press navigation key up or down to scroll through the last dialed numbers.
 - The most recently dialed number is displayed on the top of list.
3. When the desired number is displayed then press  to dial.
 - The number will remain stored until another number is dialed, thus erasing the previous number.


ICM (Intercom)

This feature allows you to hold an internal call and return to the original caller.

1. During an internal call, press navigation key left to select **System > ICM** and press 
 - The other party is on hold and hold music is heard.
2. Return to the caller on hold, press navigation key left to select **System > ICM** and press 
 - If you do not retrieve the call within a certain amount of time (set by your system administrator) you will receive an internal call only once from the other party.

Mute

Use this feature, you can turn off the microphone in your phone. The other party cannot hear you, but you can still hear them.

1. During a call, press navigation key left to select **System > Mute** and press .

or




Press **Mute** (middle softkey) to activate the mute feature.

2. Return to your phone conversation, press navigation key left to select **System > ICM** and press .




Call Transfer

The transfer feature redirects an active call to another number on the system.


To talk to the transfer recipient before transferring a call (Screened Transfer):

1. From an active call, press  once or press navigation key left to select **System > Transfer** and press .
 - The first call is on hold and hold music is heard.
2. Enter the destination number to which the call is to be transferred.
3. When the recipient answers, announce the caller.
4. press  to complete the transfer and end a call.

To transfer a call without talking to the transfer recipient (Unscreened Transfer):



1. From an active call, press  once or press navigation key left to select **System > Transfer** and press .
 - The first call is on hold and hold music is heard.
2. Enter the destination number and press  to complete the transfer and end a call.

To cancel a call transfer:

1. While you are transferring a call, press  to cancel a call transfer.
2. Transferring a call is terminated and you will be reconnected to the first caller.




Hold/Save


You can place an external call on hold to answer an incoming call or place a call.







1. During an external call, press  or press navigation key left to select **System > Hold/Save** and press .
 - The current call is on hold and the hold music will be heard.
2. Press the number to which you want call.
3. Return to the caller on hold, enter the Access Held CO code. For more information on this, please ask your system administrator.

Program

The Program allows you to set the features which required to use the WIT-400HE. Some of that features might not be supported in WIT-400HE.

1. Press  to access programing mode.
or
Press navigation key left to select **System > Program** and press .
2. When the menu displayed on the screen, use the  to scroll through the menu and press:



-   ,  to select the menu item.
-  to save the setting values (It may slightly differ depending on what menu item you set.)
-  to move back to the current menu item or go to the standby mode.

WIT-400HE is one of the phone to be recognized from the iPECS System. This chapter explains how to set the phone connects to a network as well as special features that let you manage your networks.

Profile Settings


The Profile Settings provide instructions for creating profiles and connecting to an wireless LAN in order to register your phone to the iPECS System.

Creating Profiles


Profiles are used to connect to wireless LANs. Before connecting to the selected wireless LAN, you are required to create and use a profile. Once you select the wireless LAN, the profile entry is displays.

To use phone's default profile:

1. Press **☰** > **Settings** > **Profile Setting**.
2. Select **SystemDefault**. Only this default profile can be able to support Handover between the same SSID in the different AP (access point).
3. Press **Menu** (left softkey) and select **Edit**, and then press **OK**.





4. To edit the name to use for the default profile:




- Select **Profile Name** field and enter a profile name to whatever you want.


5. To assign a profile to the wireless LAN access point:



- Select **Network Name(SSID)** field and enter a network name, and then press .
- This SSID must be exactly the same as it is in an access point which you have installed.

6. To set an encryption type to the default profile:




- Select **Security Setting** field and press navigation key left or right to select a valid value NONE, WEP-OPEN, WEP-SHARED, WPA-PSK-TKIP, WPA-PSK-AES, WPA2-PSK-TKIP, or WPA2-PSK-AES, and then press .


- The encryption method in use for this profile. An encryption type must be exactly the same as it is in a wireless LAN access point which you have installed.


7. To set authentication to the default profile:



- Select **802.1X Authentication** field and press navigation key left or right to select a valid value NONE, MD5, TTLS, PEAP, LEAP, or TLS and then press .

8. To set network to the default profile:




- Select **Network** field and press navigation key left or right to select one of DHCP or STATIC, and then press .
- IP Address must be within the same network area and all access point's IP address are within it too for supporting handover.
 - **DHCP** is client provides a mechanism for allocating IP addresses dynamically so that addresses can be reused when hosts no longer need them.
 - **STATIC** is a number that is assigned to a phone by an Internet service provider to be its permanent address on the Internet. In this case, you must manually enter the following information to set for the network.
- **IP Address:** The IP address of this phone.
- **Subnet:** The subnet mask used for the network.
- **Primary GW:** The IP address of the gateway for the network.

- **Primary DNS:** The primary IP address of the Domain Name Server for this network.
 - **Secondary DNS:** The secondary IP address of the Domain Name Server for this network.
9. After setting IP address, the phone tries to register with the system if you select this profile.

To create a new profile:

1. Press **[Left Arrow]** > **Settings** > **Profile Setting**.
2. Press **Add** (right softkey) to create the new profile.
3. To assign the name to the new profile:



- Select **Profile Name** field and enter a profile name to whatever you want.
4. Follow the applicable instructions in "To use phone's default profile:" on page 85.

To create a new profile after searching wireless LAN:

1. In standby mode, press navigation key (**[Up Arrow]**) up to search wireless LAN around the phone.




- The screen shows "Searching SSID" for a while, and then displays existing all the wireless LANs in the phone's neighborhood.
- Left part on the screen shows the security and signal strength of the network.

- **Lock icon** (🔒) indicates that the wireless LAN is encrypted. Wireless LANs that do not use encryption do not have the lock icon.
 - **Bar icon** (📶) indicates the signal strength in different states of the network.
- Right part on the screen shows the name of the network.
 - **Note:** By default, when the wireless LAN is switched on, you can easily create profile after searching for the wireless LAN to connect.
2. Use the navigation key to scroll through the profile and select one.
 - Press **Menu** (left softkey) to select an options Re-scan, View Detail, or Add Profile and then press **OK**.
 - The Re-scan is used to refresh a list of all available wireless LANs.
 3. Press **Add** (right softkey) to create the new profile.
 - **Profile Name** and **Network name(SSID)** are filled in with the SSID which you have chosen automatically.
 - You can change this profile name to whatever you want, but not network name(SSID).
 4. Follow the applicable instructions in "To use phone's default profile:" on page 85.

Connecting a Profile

You can connect to the selected wireless LAN. After creating a profile for connecting to the wireless LAN of your choice.

1. Press **Menu** > **Settings** > **Profile Setting**.
2. Select a profile you wish to use and press **OK**.



Shows the profile that you are currently using.


3. After requesting the IP, the phone tries to register with the system. Please wait for the connection to be completed.
 - When the phone has finished connecting the wireless LAN, you can see an **📶** icon on the screen in standby mode.

Managing Profiles

This menu allows you to edit, delete, and change priority profiles.

To edit an existing profile:

1. Press **[-]** > **Settings** > **Profile Setting**.
2. Select a profile you wish to edit.
3. Press **Menu** (left softkey) to display the options.
4. Select **Edit** and press **[OK]**.



5. Involves the same steps as creating a new profile. Follow the applicable instructions in "To create a new profile" on page 87.

To delete a profile:

1. Press **[-]** > **Settings** > **Profile Setting**.
2. Select a profile you wish to delete.
 - The system default profile can not be deleted from the profile entry.
3. Press **Menu** (left softkey) to display the options.
4. Select **Delete** and press **[OK]**.
5. Select **Yes** to confirm and press **[OK]**.


To change the priority of profile:

1. Press **[-]** > **Settings** > **Profile Setting**.
2. Select a profile of which you wish to change the priority.
3. Press **Menu** (left softkey) to display the options.
4. Select **Change Priority** and press **[OK]**.
5. To change the priority of a profile, select **Priority Up** or **Priority Down** and press **[OK]**.
 - Depending on the action chosen, the profile is moved up or down the entry list.


System Setting

WIT-400HE should be set to register with the iPECS system for normal interaction with a Multi Function Interface Module (MFIM) in the iPECS system. These menus are all related to the MFIM configuration.

1. Press **[-]** > **Settings** > **System Setting**.
2. Enter your security code and then press **[OK]**.
 - The preset code is "0000".
3. **Direct Send** can be configured depending on the network status, press the navigation key left or right to select **Yes** or **No**.



- WIT-400HE can automatically locate MFIM when **Direct Send** value is set to **No**. This allows a user to register to the MFIM without knowing its IP address by setting this value to **No**.
 - If there are more than one MFIM in the same IP subnet, a user can selectively register to a MFIM by setting its value to **Yes**.
4. **Remote Mode** can be configured depending on the IP range of the network between the iPECS system and WIT-400HE, press the navigation key left or right to select **Yes** or **No**.



- Now your iPECS system, your AP and WIT-400HE are in the same IP range, select this value to **No**.
- In other cases, you should select this value to **Yes**.

5. **System IP** must manually enter with the same IP address of the iPECS system in order to initially request for registration to the iPECS system.



6. **Station Set** (extension number for the station) can be entered manually depending on the system you want to register.



- In case of the iPECS-CM, the number you entered is registered as the extension number when WIT-400HE registered to the iPECS-CM.




Codec Preference

A codec is a device program capable of encoding or decoding a digital data signal.

1. Press **[Left Arrow]** > **Settings** > **Cordec Preference**.
2. Enter your security code and press **[Right Arrow]**.
 - The preset code is "0000".
3. Press the navigation key left or right to select a supported codec for WIT-400HE.
 - Supportable codec: System Codec, G.711, G.729, and G.722.
4. Press **[Right Arrow]** to apply the setting.




Wireless LAN Setting

You can adjust a roaming level to find the best access point signal within close proximity to each other while moving around.

1. Press  > **Settings > Wireless LAN Setting**.
2. Enter your security code and press .
 - The preset code is "0000".
3. Press the navigation key left or right to select a roaming level.
 - The higher the value of the roaming level can be found access point easily. You are in network coverage, your phone attempts to find a signal depending on the setting value.
4. Press  to apply the setting.



Security

All of your phone's security settings are available through the security menu which helps you to protect against unauthorized users.

1. Press  > **Settings > Security**.
2. Enter your security code and press  to display the security menu.
 - You must enter your security code to view the security menu.
 - The preset code is "0000", use this you can access to the security menu for the first time.
3. Security has 6 sub-menus and displayed , select one item from each of the following menus to set:
 - **Lock phone** to prevent access by unauthorized users. When your phone is locked, you can only answer calls.
 - **Change codes** to change your security code to whatever you like. (Enter and reenter your new security code, pressing  after each.)



Wireless LAN Status

This menu allows you to view the specific information about the wireless LAN.

1. Press  > **Settings > Wireless LAN Status**.
2. Displays the wireless LAN MAC, SSID, Signal, security, and channel.
3. Read the information provided on the phone's display and press  to return to the previous menu.



Network Information

This menu allows you to view the information on using the network configuration.

1. Press  > **Settings** > **Network Information**.
2. Displays the IP address, netmask, gateway, DNS1, and DNS2.
 - The DNS2 property defines the secondary DNS address.
3. Read the information provided on the phone's display and press  to return to the previous menu.




Phone Version

This menu allows you to view the software version of your phone.

1. Press  > **Settings** > **Phone Version**.
2. Displays the software version, MAC address, and serial number of your phone.
3. Read the information provided on the phone's display and press  to return to the previous menu.

Reset Settings

This menu allows you to reset the phone to its original state.

1. Press  > **Settings** > **Reset Settings**.
 2. If you are certain you want to reset the phone, select **Yes**.
 - Enter your security code as it is a required field and then press  .
 - **Note:** Be careful when using this menu, after rebooting all your settings are initialized to their original values.
- or
- Select **No** to cancel and return to the previous menu.
3. Press  to save the date and time.




Before Service Inquiry

This appendix contains before service inquiry and troubleshooting information that will help you use your phone.


Check the following checkpoints before contact the customer service center. If you have question or need assistance, please consult your local service center.

Note: For the best care of your phone, only authorized personnel should service your phone. Failure to do so may be dangerous and void your warranty.

The phone does not work at all.

- Check if the travel adaptor for the charger is properly connected to the electrical outlet. (Refer to "To install the charger" on page 15.)
- Check if the phone's battery is sufficiently charged referring to battery charge level icon on the screen in standby mode.
- If the phone does not work after power on, install the battery again and then restart your phone. (Refer to "Installing and Removing the Battery" on page 13.)
- Press and hold  for three seconds to turn on the phone. Check if the opening message is displayed and then Antenna  and RSSI level  icon are displayed on the screen.

The Seamless Handover does not work in the same network configuration.

- Make sure that the "SystemDefault" profile is selected with a check mark  from **Menu > Settings > Profile Setting**. Only system default profile can be supported seamless handover between the same SSID in the different access point.

- Phone profile's network configuration must be the same as you are currently using on the installed network. (Refer to "To use phone's default profile" on page 89.)
- Check your roaming level from **Menu > Settings > Wireless LAN Setting**. The roaming level enables you to roam with a voice connection between each access point while you are speaking. The default roaming level is -75 dBm. (Refer to "Wireless LAN Setting" on page 97.)

The phone can not show a wireless LAN access point even though the phone within its range.

- The LAN access point may use a hidden service set identifier (SSID). You can only access networks that use a hidden SSID if you know the correct SSID, and have created a LAN internet access point for the network on your phone.

The phone call quality is no good.

- **Note:** Some times while using the phone, suppose due to radio interference (depending on various factors, such as the mobile phone's network, other access point) can be a cause of your call will be dropped.
- Check if you are using the phone an area with high electrical interface, such as antenna or mobile phone.
- Check if the distance between the access point and the phone is too long, move closer to access point.
- Avoid touching the antenna area unnecessarily while the antenna is transmitting or receiving. Contact with the antenna affects communication quality.
- Signal intensity could be weakened by obstacles, such as walls or electromagnetic interference.

The phone ring is mute or too weak.

- Check if ring mode is set to always off and adjust it properly from **Menu > Sound > Ring Tone Volume**.
- During a call if the receiving volume is small, press the side volume key to adjust the volume to a desired level.

The phone's display screen is not clearly visible.

- Adjust the brightness from **Menu > Display > Backlight**.

The phone does not function normally.

- Select **Menu > Settings > Reset Settings**. This feature will reset all custom settings back to factory default. You cannot stop the process after you start it.
- **Note:** When you reset the phone, you will have to set it up all over again to your liking. Be sure to separately keep the input, settings or important data.

The phone is too warm.

- The phone may be heated when it used for a long time but this dose not affect the lifetime and performance of the phone.

The battery fully charged, but battery icon still blinks.

- Make sure that the battery is install correctly and clean the phone's charging contacts and then charge again.
- It is time to replace the battery.

Troubleshooting

If you experience any problems with the normal use of your phone, you should remove and replace the battery, then turn on the phone.

Symptoms	Troubleshooting Guide
Failed to scan AP	Scanning access point is failed. Try again and if it fails too, check the access point status.
Encryption key is not valid	The encryption key is not matched with access point's. Please check encryption key of the phone.
DHCP Failed	The phone; didn't received response for the IP request. Please try again and if it fails too, check the DHCP server.
Static IP configure failed	The static IP is not valid. Please check the IP configuration.
Network connection fail	The registering is failed by network failure. Please check the network status and IP configuration.
Out of range	The phone is off from signaling area. Please move to signaling area.
Disconnected by network failure	The signaling is failed by network failure. Please check network status.
IP is duplicated	Please check the IP is used in other device.
User Info not registered	The SIP registration data is not registered on the system. Please set the data to register, such as phone number and password.
Register failed. Please check user info	System responded error message on registering request. Please check SIP information such as password.
Please check phone number	The phone number is not defined on the system. Please check the system login IDs on Menu 443.
Can't register to system	System responded error message on registering request. Please check the SIP configuration of the phone and system.

Specification

Please note that all specifications are subject to change without notice due to product improvements.

Radio:	
Wireless standard	IEEE 802.11b/g
Tx Frequency (GHz):	2.412GHz ~ 2.472GHz (Operating band)
Rx Frequency (GHz):	2.412GHz ~ 2.472GHz (Operating band)
Output power	Under 20dBm IEEE 802.11 b/g
Operating range	50m (In office), 200m (Open site)
Transmit data rate	- 802.11b : 1, 2, 5.5, 11Mbps - 802.11g : 1, 2, 5.5, 6, 9, 11, 12, 18, 24, 36, 48, 54 Mbps
VoIP protocol	ipKTS
Codec	G.711(A/U law) / G.729 / G.722
Wired encryption	TBD (future : IPsec)
Wireless encryption	WEP : Support Disabled, 64bit, 128bit, WPA-PSK, WPA2-CCMP
Compatible systems	iPECS-LIK(50/100/300), iPECS-CM
Wireless access protocol	CSMA/CA
QoS	IEEE 802.11e
Other	This phone can potentially occur radio interference while the phone is in use. WIT-400HE implements security and encryption technologies however, privacy of communications may not be ensured when using this phone.

Adapter:

Adaptor input power	AC100~240V, 50/60Hz, 0.15A
----------------------------	----------------------------

Adaptor output power	5.1V 0.7A
-----------------------------	-----------

Operating temperature	0°C ~ 40°C
------------------------------	------------

Battery:

Continuous standby time	Approximately 50 hours
--------------------------------	------------------------

Continuous talk time	Approximately 3 hours
-----------------------------	-----------------------

Estimated charging time	Approximately 6 hours
--------------------------------	-----------------------

Battery type	Li-Ion (Lithium Ion) 3.7V 1150mAh
---------------------	-----------------------------------

LCD:

Type	2 inches TFT Graphic LCD 65K colors
-------------	-------------------------------------

Dot	176 x 220 dot matrix
------------	----------------------

Product:

Dimension,(±5mm)

- WIT-400H	135 x 47 x 20mm (H x W x D)
------------	-----------------------------

- Charger	78 x 88 x 92mm (H x W x D)
-----------	----------------------------

Weight (±50g)

- WIT-400H	100g (Battery included)
------------	-------------------------

- Charger	73g
-----------	-----

Caring for the Battery

Protecting Your Battery

The guidelines listed below help you get the most out of your battery's performance.

- Recently there have been some public reports of phone batteries overheating, catching fire or exploding. It appears that many, if not all, of these reports involve counterfeit or inexpensive, aftermarket-brand batteries with unknown or questionable manufacturing standards. Use only Ericsson-LG approved batteries and accessories.
- In order to avoid damage, charge the battery only in temperatures that range from 32° F to 113° F (0° C to 50° C).
- Do not use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.
- Never dispose of the battery by incineration.
- Keep the metal contacts on top of the battery clean.
- Do not attempt to disassemble or short-circuit the battery.
- The battery may need recharging if it has not been used for a long period of time.
- It is best to replace the battery when it no longer provides acceptable performance. It can be recharged hundreds of times before it needs replacing.
- Do not store the battery in high temperature areas for long periods of time. It is best to follow these storage rules:
 - Less than one month: -4° F to 113° F (-20° C to 40° C).
 - More than one month: -4° F to 113° F (-20° C to 45° C).

Disposal of Lithium Ion (Li-Ion) Batteries

Do not handle a damaged or leaking Li-Ion battery as you can be burned.

For safe disposal options of your Li-Ion batteries, contact your nearest Ericsson-LG authorized service center.

Special Note

Be sure to dispose of your battery properly. In some areas, the disposal of batteries in household or business trash may be prohibited.

Open Source Software Notice

This following GPL (General Public License) software used in this product are subject to the GPL License Agreements.

You can obtain a copy of the GPL licenses from Ericsson-LG Web Site (<http://www.lgericsson.com>).

GPL License:

- u-boot
- bash
- linux
- busybox
- glibc
- wpa supplicant
- udhcpc
- ortp
- jpglib
- wget
- wireless Tools

Ericsson-LG offers to provide source code to you on CD-ROM for a charge covering the cost of performing such distribution, such as the cost of media, shipping and handling upon e-mail request to Ericsson-LG at. :

opensource@lgericsson.com.

This offer is valid for a period of three (3) years from the date of the distribution of this product by Ericsson-LG.

Caring for the Environment by Recycling



This symbol means that the your phone or other electrical accessories should not be disposed of with household waste.

■ Do not throw your phone or battery in the trash.

Disposal of your old appliance

1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

A

- Access Point 23
 - Max retry counter 24
 - Recommended AP 24
 - Reject after Full Association 24
 - Roaming 24
 - The simultaneous calls 24
- Access Point Probing 27
- Alarm Clock 71
 - Deleting 72
 - Deleting All 72
 - Editing 72
 - Setting 71
- Alert By 47
- Alphanumeric Keypad 8
- Answering Calls 34

B

- Backlight 53
- Battery 13
 - Charging 15
 - Installing 13

Battery Cover 9

C

- Calculator 73
- Call Duration 57
 - Resetting 57
 - Viewing 57
- Caller ID 26
- Call Forward
 - Activating Call Forward 77
 - Busy (B) 77
 - Busy/ No Answer (BN) 77
 - Deactivating Call Forward 78
 - No Answer (N) 77
 - Unconditional (U) 77
- Call History 55
 - Making a Call 56
 - Options 56
 - Viewing 55
- Call Options 34
- Charger Jack 9
- Charging 15

Clear Key 9

D

Dialing Font 52

Display Screen 10

Display Informations 10

Main Menu 11

Main Menu Icons 12

State Displays 12

Status Icons 10

E

Earpiece 8

Effect Sound 49

Ending a Call 34

End/Power Key 8

Entering Text 18

123 Mode 19

ABC Mode 18

Symbols and Templates 20

Text Input Mode 18

F

Finding Number 32

Font Type 53

G

Greeting Note 52

H

Handover 99

Headset 21

Connecting 21

Headset Jack 9

Hold

Access Held CO code 88

I

Idle Clock 52

K

Key Functions 8

Key Tone 49

Key Tone Volume 49

L

Language 54

Left Softkey 8

Lock Mode 9, 35

M

Main Menu Icons 12

Making Calls 31

Call History 32

Dialing Options 33

Finding Number 32

Last Number 33

Phone Book 32

Phone Number 31

Speed Dial 33

Manner Mode 8, 35

Memo 70

Composing 70

Deleting 70

Deleting All 71

Menu Style 53
Messages
 Draft 62
 Inbox 61
 Outbox 62
 Receiving Message 59
 Templates 63
 Voice Message. **See** Call Forward
 Writing Text Message 60
Mic 8

N

Navigating Through Menus and Options 17
 Corresponding Number 17
 Menu Items 17
Navigation/OK Key 8
Network Information 98
Network Name 90. **See** SSID

P

Package 5
Phone Book (Contact)
 Adding 38
 Caller Groups 41
 Deleting Entries 46
 Searching Entries 40
 Speed Dials 44
 Storing Numbers Faster 39
Phone Carrying 22
 Belt Clip 22

Wrist Strap 22
Phone Layout 7
Phone On and Off 16
 Phone Off 16
 Phone On 16
Phone's Menu 28
Phone Version 98
Power-On Tone 48
Profile Settings 89
 Connecting a Profile 93
 Creating Profiles 89
 Managing Profiles 94

Q

Quickly Change Mode 35
 Lock Mode 35
 Manner Mode 35
 Quickly Set to Vibrate 35

R

Range 26
Recycling 107
Registration
 iPECS Setup 26
 Wireless LAN Connection 26
Reset Settings 98
Restarting 26
Right Softkey 8
Ring Tone 47
Ring Tone Volume 48

S

- Schedule 65
 - Adding 66
 - Deleting 67
 - Going to Today 69
 - Searching 69
 - Setting your Holiday 68
 - Specific Event 69
 - Viewing 66
- Schedule Key 8
- Screen Theme 51
- Searching Entries 40
- Security 97
 - Change codes 97
 - Lock phone 97
 - preset code 97
- Side Volume Key 9
- Signal Strength 27
- SIP Setting 95, 96
- Speaker 9
- Specification 103
- Speed Dials 44
- SSID 26. **See** Network Name
- Strap Eyelet 9
- System 77
 - Call Forward 77
 - Call Waiting 80, 82, 86, 87, 88
 - Do Not Disturb (DND) 79, 80
- System Speed
 - Character Input Table 85

- CO Code 83
- Deleting a Speed Dial 85
- Storing a Speed Dial 82
- Using a Speed Dial 84

T

- Talk key 8
- Timer 74
 - D-Day Counter 74
 - D-Day Finder 74
 - Stopwatch 75

W

- Wireless LAN Setting 97
- Wireless LAN Status 97
- World Time 73

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. Ericsson-LG shall have no liability for any error or damage of any kind resulting from the use of this document.



ISSUE 1.0

Posted in Korea

www.ericssonlg.com

© Ericsson-LG Co., Ltd. 2013